





# H5163 / H5163 R

© Copyright Powerscreen 2008

H5163 R MODEL



H5163 MODEL

## PRODUCT USER MANUAL OPERATION INSTALLATION MAINTENANCE

**WARNING WARNING WARNING WARNING WARNING**



DO NOT ATTEMPT TO OPERATE THIS PRODUCT UNLESS  
YOU HAVE READ AND UNDERSTOOD THESE SAFETY INSTRUCTIONS.  
FAILURE TO DO SO WILL INCREASE  
THE RISK OF INJURY OR MAY RESULT IN DEATH!





**SUBJECT TO CHANGE WITHOUT PRIOR NOTICE!**  
**IMPORTANT SAFETY NOTICE!**

Read this manual carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.

Consider this manual a permanent part of your machine.

Keep a copy of this manual at the operational site.

Follow all applicable safety regulations and recommendations in this manual as appropriate to your product and the situation/conditions prevailing at the time. Federal, State, National and Local laws and safety regulations must be complied with at all times to prevent possible danger to person(s) or property from accidents or harmful exposure.

See also the separate Operation and Maintenance Manual provided for the diesel engine if fitted to your product and in particular read and observe the instructions within the Safety Section of the engine manual

**INFORMATION AND ADVICE**

**If you need any information or advice regarding your Powerscreen Product, contact:-**

**Northern Ireland:**

Powerscreen International Distribution  
200 Coalisland Rd  
Dungannon  
Co. Tyrone  
BT71 4DT

**Telephone:**

Main Switchboard:  
+ 44 (0) 2887 740701

**Email:**

[aftersales@powerscreen.com](mailto:aftersales@powerscreen.com)


**America**

Terex Crushing & Screening Inc.  
11001 Electron Drive  
Louisville,  
Kentucky 40299  
United States of America

**Telephone:**

Main Switchboard:  
001 (502) 736 5200





#### **EC - Conformity**

POWERSCREEN product machinery are in conformity of the EC Machinery Directive guideline 98/37/EEC and supplement thereto.



#### **Noise Level - Hearing Harard dB (A) Levels**

POWERSCREEN product machinery are tested according to guideline 2000/14/EC.

This machine falls below these values.

#### **CALIFORNIA**

##### **Proposition 65 Warning**

WARNING: Battery Posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.

**WASH HANDS AFTER HANDLING.**

#### **CALIFORNIA**

##### **Proposition 65 Warning**

WARNING: Diesel engine exhaust and some of it's constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



**The Operator must read and understand all the instructions in this manual before operating the machine.**

**Owners, Users, and Operators:** Powerscreen International Dis. Ltd. appreciates your choice of our product for your application. Our number one priority is user safety which is best achieved by our joint efforts. We feel that you can make a major contribution to safety if you as the equipment users and operators:

1. **Comply** with OSHA, Federal, State, and Local Regulations.
2. **Read, Understand, and Follow** the instructions in this and other manuals supplied with this product.
3. **Use Good, Safe Work Practices** in a common sense way.
4. **Only have trained operators** — directed by informed and knowledgeable supervision — operating this product.

If there is anything in this manual that is not clear or which you believe should be added, please send your comments to:

**Help Desk ([aftersales@powerscreen.com](mailto:aftersales@powerscreen.com))**

**Main Switchboard: + 44 (0) 2887 740701**

**Fax: + 44 (0) 2887 74718649**

**Powerscreen International Distribution, Dungannon, Co. Tyrone BT71 4DR.**



**The safety alert symbol is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.**

## Intended use

This product and its approved attachments are designed to perform screening. Use of this product in any other way is prohibited and contrary to its intended use.

The list of terms below, can be found throughout the following manual.

**A-Frame**

A frame that is mounted at each end of the drum (only on Trommels). Used to ensure drum is sealed correctly.

**Anti Rock Stay**

A strap which is used to stabilise the screen unit whilst in transport.

**Antiluce Fastener**

A type of fastener used to secure some doors.

**Assemblies**

Individual sections of the machine made up of different components parts.

**Auxiliary Control Valve**

A bank of hydraulic valves which carry out various movement functions throughout the machine.

**Belt Scraper**

A device fixed or flexible mounted across the width of a belt of a conveyor for removing adherent material.

**Bogie**

Undercarriage on chassis to which axles are bolted.

**Centre Roller**

A roller, which supports the loaded belt.

**Collection Conveyor**

A conveyor used to transfer the fines material from underneath the drum onto the incline conveyor.

**Control Panel**

A panel that is situated in the powerunit which is used to start the engine and view the various warning lights.

**Controller**

An electromechanical device or assembly of devices for starting, stopping, accelerating, or decelerating a drive, or serving, to govern in some predetermined manner the power delivered to the drive.

**Conveyor**

A horizontal, inclined, or vertical device for moving or transporting bulk material, packages, or objects, in a path determined by the design of the device, and having points of loading and discharge, fixed or selective.

**Conveyor belt**

A belt used to carry materials and transmit the power required to move the load being conveyed.

**Conveyor, extendable**

A conveyor that may be lengthened or shortened to suit operating needs.

**Conveyor, live roller**

A series of rollers over which objects are moved by the application of power to all or some of the rollers. The power transmitting medium is usually belting or chain.

**Conveyor, mobile**

Conveyor, supported on a structure, and includes, but is not limited to, radial stackers, winged stackers, reclaiming conveyers, and shipholders. These conveyors normally handle bulk material.

**Conveyor, portable**

A transportable conveyor which is not self-propelled, usually having supports that provide mobility.

**Conveyor, screw**

A conveyor screw revolving in a suitably shaped stationary trough or casing fitted hangers, trough ends, and other auxiliary accessories.

**Control Valve**

A hydraulic valve, which carries out a movement function on the machine.

**Depressurised**

To release the pressure from a vessel i.e. a tyre, hydraulic system.

**Discharge Area**

The area where material is dumped from the machine.

**Dolly Axle**

An axle that can be fitted to king pin, used for towing purpose.

**Drive**

An assembly of the necessary structural, mechanical, and electrical parts provide the motive power to change direction.

**Drive Drum**

The drum that drives the conveyor belt sometimes called the head drum.

**Drum**

A cylindrical or polygonal rim type of wheel around which cable, chain, belt, or other linkage may be wrapped. A drum may be drive or driving. The face may be smooth, grooved, fluted, or flanged.

**Drum Lagging**

Rubber glued around the drive drum to grip the conveyor belt.

**Feed Conveyor**

Conveyor used to move the material from the hopper to the main conveyor.

**Feedboot**

An extended metal surround located at the bottom of the main, tail & side conveyors.

**Feeder Unit**

Conveyor which feeds the material onto the incline conveyor at an even rate.

**Filler Cap**

A cap used to seal a tank and is removed in order to fill the tank.

**Fines Material**

Material that is screened through the lower screen deck and is discharged on to the tail conveyor.

**Four Bank**

A bank of hydraulic control valves used to control functions of the machine.

**Flywheel**

A half moon shaped counter weight, which is mounted on the screen unit shaft for the purpose of counter acting the weight of the eccentric of the screen shaft.

## **Gate**

A device or structure by means of which the flow of material may be stopped or regulated; also a section of a machine equipped with a hinge mechanism for movable service often called a hingesction.

## **Grid Aperature**

The spacing between the grid bars (typically 100mm) which determines the material size that enters the feed hopper.

## **Grid Bar**

Bars used on the grid spaced out with equal spacing. Used to roughly screen material.

## **Grating**

A course screen made of parallel and crossed bars used to prevent passage of oversized material.

## **Guard**

A covering, barricade, grating, fence, or other form of barrier used to prevent inadvertent physical contact with operating components such as gears, spockets, chains, and belts.

## **Hopper**

A box having a funnel shaped bottom, or a bottom reduced in size, narrowed, or necked to receive material and direct it to a conveyor, feeder, or chute.

## **Hydraulic Components**

A part used in the hydraulic system of the machine i.e. valve, motor etc.

## **Hydraulic Screen Tension**

The assistance of hydraulic rams when tensioning the screen meshes.

## **Jacking legs**

Hydraulic adjustable legs which raise or lower the back of the machine for the purpose of coupling to the tractor unit.

## **King Pin**

Coupling used for towing by the tractor unit.

## **Landing Leg**

A support leg which lowers from the machine and is used to stabilise it whilst in the working position.

## **LHS**

Left Hand Side, used with reference to the side conveyors.

## **Lockout**

Procedure to be carried out to ensure the machine is safe for maintenance or repairs

## **Machine Stop**

A stop arising from a sudden and unexpected need, and not as a part of the normal operation.

## **Main Conveyor**

Conveyor used to move the material from the hopper to the screen unit.

## **Nip Point**

A point at which a machine element moving in line meets a rotating element in such a manner that it is possible to nip, pinch, squeeze, or entrap a person or objects coming into contact with one or two of the members.

## **Optimum Speed**

The best or most favourable speed to run a conveyor for example.

## **Oversize material**

Material that is larger than the mesh size and runs off the top screen deck.

## **Platform**

A working space for persons, elevated above the surrounding floor or ground for the operation of machinery and equipment.

## **Prevent**

When used in a context such as prevent access or prevent physical contact, means to impede or block; when used in a context such as prevent injury, means to reduce the chances of, but does not imply that an injury cannot occur.

## **Powerunit**

An inclosed unit situated under the main conveyor which houses the component parts which together drive the machine.

## **P.S.I**

Pounds per square inch. Unit of Pressure. Conversion 1 Bar = 14.5 P.S.I

## **Rated speed**

The speed, as established by the manufacture or a qualified person, at which safe and satisfactory service can be expected.



**Return Roller**

A roller, which is used to support the unladen belt on the underside of the conveyor.

**Recommissioning**

To prepare the machine for use.

**Reject Grid**

An arrangement of equally spaced grid bars which is used to separate the large stones before the material enters the feed hopper.

**Retract**

Withdraw or fold up conveyor.

**Remote control**

Any system of controls in which the actuator is situated in a remote location.

**RHS**

Right Hand Side, used with reference to the side conveyors.

**Safety device**

A mechanism or an arrangement placed in use for the specific purposes of preventing an unsafe condition, preventing the continuation of an unsafe condition, warning an unsafe condition,  
or limiting or eliminating the unsafe effects of a possible condition.

**Scraper**

A device fixed or flexibly mounted across the width of a belt of a conveyor for removing adherent material.

**Screen Drum**

Drum which mesh is fitted onto rotates during operation to screen material (Trommel).

**Sound Baffles**

Plates used to blank out noise from the powerunit.

**Screen Unit**

Vibratory unit used to separate by size raw materials.

**Should**

As used in the context of a provision of this manual, indicates a recommendation, the advisability of which depends on the facts in a particular situation.

## **Shredder Safety Stay**

Metal strap which restrains the shredder unit whilst in the raised position.

## **Take-up**

The assembly of the necessary structural and mechanical parts that provides the means to adjust the length of belts, cables, chains, etc. to compensate for stretch, shrinkage, and wear.

## **Shredder Unit**

Swinging fail type unit which is located at the discharge end of the feed conveyor and is used to break down material.

## **Side Conveyor**

Conveyor used to collect the material from the screen unit and move it to the discharge area at 90 degrees to the main machine.

## **Side Roller**

Roller used to create arc on the belt to reduce spillage.

## **Spillage**

Material that spills over the edge of a conveyor etc.

## **Spill guard**

A stationary device of sufficient strength and capacity to catch, retain, and contain any reasonably foreseeable spillage from a conveyor passing overhead.

## **Spreader Plate**

Swinging plate located at the discharge end of the main conveyor and is used to spread the material evenly on the screen unit.

## **Sprocket**

A toothed wheel arranged to fit into the links of a chain.

## **Strut**

Rigid support used to hold an assembly in place.

## **Swivel Conveyor**

Conveyor used to discharge fines material. Swivel through 180° to increase stockpiling capacity.

**Tail Conveyor**

Conveyor used to collect the fines material from the screen unit and move it to the discharge area.

**Tow pin**

A movable or fixed member, used to engage a push or pull.

**Telescopic Head Section**

A section of a conveyor which extends out telescopically into transport position.

**Tracks**

The beams, shapes, or formed section on which trolleys, rollers, shoes, or wheels roll or slide while propelled.

**Transport Bracket**

A bracket used to hold an assembly in place whilst in transport.

**Transport Position**

The position of the machine when conveyors are folded.

**Variable Speed Flow Control**

A device which is used to hydraulically vary the speed of the conveyor belt.

**Viewing Apertures**

Opening holes to view the conveyor belt.

**Vulcanized Belt**

A conveyor belt that has been joined seamlessly using a special treatment.

**Wheel Nut Torque**

A measure of pressure applied to tightened a nut.



|           |                               |           |
|-----------|-------------------------------|-----------|
| <b>0</b>  | <b>Safety</b>                 | <b>00</b> |
| <b>1</b>  | <b>Technical Information</b>  | <b>01</b> |
| <b>2</b>  | <b>General Information</b>    | <b>02</b> |
| <b>3</b>  | <b>Design and Function</b>    | <b>03</b> |
| <b>4</b>  | <b>Transport</b>              | <b>04</b> |
| <b>5</b>  | <b>Set up</b>                 | <b>05</b> |
| <b>6</b>  | <b>Operating Instructions</b> | <b>06</b> |
| <b>7</b>  | <b>Shut off</b>               | <b>07</b> |
| <b>8</b>  | <b>Maintenance</b>            | <b>08</b> |
| <b>9</b>  | <b>Appendix</b>               | <b>09</b> |
| <b>10</b> | <b>Trouble Shooting</b>       | <b>10</b> |
| <b>11</b> | <b>Fault Finding</b>          | <b>11</b> |
| <b>12</b> | <b>Servicing Tracks</b>       | <b>12</b> |

## Contents

|         |  |    |
|---------|--|----|
| 0.1.1   | Warnings and symbols.....  | 2  |
| 0.1.2   | Personal safety.....   | 3  |
| 0.1.3   | Work area safety.....  | 4  |
| 0.1.4   | Equipment and tools.....   | 4  |
| 0.1.5   | Lockout and Tagout.....  | 4  |
| 0.1.6   | Organizational measures.....   | 5  |
| 0.1.7   | Selection and qualification of personnel -<br>Basic responsibilities.....  | 7  |
| 0.1.8   | Safety instructions governing specific operational phases.....   | 7  |
| 0.1.8.1 | Standard operation.....  | 7  |
| 0.1.8.2 | Special work in conjunction with utilization of the machine/plant<br>and maintenance and repairs during operation; disposal of<br>parts and consumables..... | 8  |
| 0.1.9   | Warning of special dangers.....  | 10 |
| 0.1.9.1 | Electric energy.....   | 10 |
| 0.1.9.2 | Gas, dust, steam and smoke.....  | 12 |
| 0.1.9.3 | Hydraulic and pneumatic equipment.....   | 13 |
| 0.1.10  | Transporting and towing - recommissioning.....   | 14 |
| 0.1.11  | Position of emergency stops.....   | 15 |
| 0.1.12  | Machine safety decals.....   | 17 |
| 0.1.13  | Machine decal hazard locations.....  | 29 |

## 0.1.1 Warnings and symbols

### Safety Alert Symbol

The safety alert symbol is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### Safety Alert Symbol



### Hazard Classification

A multi-tier hazard classification system is used to communicate potential personal injury hazards. The following signal words used with the safety alert symbol indicate a specific level of severity of the potential hazard. Signal words used without the safety alert symbol relate to property damage and protection only. All are used as attention-getting devices throughout this manual as well as on decals and labels fixed to the machinery to assist in potential hazard recognition and prevention.



**DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



**WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



**CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



**CAUTION** used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.



## 0.1.1 Warnings and symbols Symbols - CONTINUED

### Safety Sign Maintenance

Replace any missing or damaged safety signs. Keep operator safety in mind at all times. Use mild soap and water to clean safety signs. Do not use solvent-based cleaners because they may damage the safety sign material.

### 0.1.2 Personal Safety

Powerscreen equipment is designed with the safety of all personnel in mind.

Never attempt to change, modify, eliminate or bypass any of the safety devices installed at the factory. Guards, covers and shields installed around moving parts at the factory are meant to prevent accidental injury to operators and other personnel. Do not remove them.

Make sure that everyone working on or near this equipment is familiar with safety precautions.

### **Powerscreen Int. Dis. Ltd recommends the following basic safety practices:**

- Read all danger, warning, caution and notice signs.
- Always lock out and tag out involved energy sources before performing maintenance or adjustments on this equipment. Make it impossible for anyone to start this machine while others work on it or in it.
- Never remove any guard, cover or shield when this equipment is in motion.
- Replace guards, covers and shields when the task for which you removed them is finished.
- Block parts as necessary to prevent their sudden movement while people are working on the machine.
- Wear proper personal protective equipment, including eye protection, hard hat and safety shoes, whenever you're near this machine while it is running.
- Dress appropriately in every way. Never wear loose clothes, long hair, coat tails, jewelry, pockets full of tools or any other item that could get caught in moving parts.
- Know where your fellow workers are. Always look around and inside this machine before starting it. Make sure nobody is in the way of moving parts or working on the machine.
- Report any defective machinery or equipment and unsafe conditions or activity to your boss immediately.
- Don't limit safety practices to the few rules listed here. Think safety and act safely at all times.
- Most of all, know your equipment. Understand the machinery, the conditions under which it operates and what it is capable of doing.

## 0.1.3 Equipment & Tools

- Keep the work area as neat and clean as practical.
- Keep all product safety signs clean, clear and current. Replace any damaged or missing safety signs.
- Make sure all electrical equipment is properly grounded. Wet spots near electrical current are especially dangerous.
- Store hazardous materials in restricted access areas and mark them clearly. Federal regulations require special labeling of certain materials.
- Never start an engine in an enclosed space without properly venting the exhaust.
- Do not smoke or allow smoking near fuels and solvents. Never strike a spark or use an open flame near fuels and solvents.
- Store flammable fuels, solvents and gases in secure, well ventilated areas. Never allow fumes to accumulate in the storage area. Use nonflammable solvents for cleaning parts and equipment whenever possible.
- Know where fire extinguishers and other fire suppression equipment are located. Learn how to use them effectively.
- Be alert and wary around any pressurized system, hydraulic or pneumatic. High pressure oils and gases are very dangerous.

## 0.1.4 Equipment & Tools

- Clean tools that are properly labeled and stored are safer tools. Keep your tools in good order.
- Keep drive belts and sheaves in good condition. Frayed belts or cracked sheaves are not only dangerous, they cost you downtime.
- Always use mechanical assistance to lift heavy loads. Never overload a hoist, crane, jack or other lifting device. Check lifting tackle regularly; replace it at the first sign of stretch, fraying or other wear.
- Keep your equipment clean, free of dirt and grease, so that loose, cracked or broken parts are more easily spotted. Replace defective parts as soon as they are discovered.

## 0.1.5 Lockout & Tagout

Code of Federal Regulations number 1910.147 requires that employers establish and follow a Lockout & Tagout procedure and train their employees in that procedure before any employee can operate, service or maintain any piece of power equipment. Employers are required to make periodic inspections to see that their Lockout & Tagout procedures are being followed, and they must monitor and update their program on an ongoing basis. Employees are responsible for seeing that equipment is locked out and tagged out in accordance with the employer's policy.

## 0.1.6 Organisational measures

### 0.1.6.1

Loose or baggy clothing can get caught in running machinery.

Where possible when working close to engines or machinery, only do so when they are stopped.

If this is not practical, remember to keep tools, test equipment and all other parts of your body well away from the moving parts.

For reasons of safety, long hair must be tied back or otherwise secured, garments must be close fitting and no jewellery - such as rings - may be worn. Injury may result from being caught up in the machinery or from rings catching on moving parts.

Always wear correctly fitting (EN/ANSI approved) protective clothing.

Protective clothing includes Hard Hat, Safety Glasses, Ear Protection, Close fitting Overalls, Steel Toed Boots and a High Visibility Vest.

### 0.1.6.2

You can be injured if you do not obey the safety instructions as indicated on warning stickers.

Observe all safety instructions and warnings attached to the machine!

See to it that safety instructions and warnings attached to the machine are always complete and perfectly legible.

Keep warning and instruction labels clean.

Replace unreadable or missing labels with new ones before operating the machine. Make sure replacement parts include warning or instruction labels where necessary.

## 0.1.6 Organisational measures - CONTINUED

### 0.1.6.3

Never make any modifications, additions or conversions which might affect safety without the supplier's approval.

In the event of safety-relevant modifications or changes in the behaviour of the machine during operation, stop the machine and lock out immediately and report the malfunction to the competent authority/person.

### 0.1.6.4

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, clean, service or adjust machine while it is moving. Keep hands, feet and clothing clear of power driven parts and in-running nip points. Disengage all power and operate controls to relieve pressure. Stop the engine. Implement lockout procedure. Allow the machine to cool.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn and broken parts. Remove any build up of grease, oil or debris.

Disconnect battery ground cable before making adjustments on electrical systems or welding on machine.

For the execution of maintenance work, tools and workshop equipment adapted to the task on hand are absolutely indispensable.

## **0.1.7 Selection and qualification of personnel - Basic responsibilities**

### **0.1.7.1**

Any work on and with the machine must be executed by reliable, authorised personnel only. Statutory minimum age limits must be observed.

### **0.1.7.2**

Work on the electrical system and equipment of the machine must be carried out only by a skilled electrician or by instructed persons under the supervision and guidance of a skilled electrician and in accordance with electrical engineering rules and regulations.

### **0.1.7.3**

Work on the hydraulic system must be carried out only by personnel with special knowledge and experience of hydraulic equipment.

## **0.1.8 Safety instructions governing specific operational phases**

### **0.1.8.1.1**

Take the necessary precautions to ensure that the machine is used only when in a safe and reliable state.

Operate the machine only if all protective and safety-oriented devices, such as removable safety devices, emergency shut-off equipment, sound-proofing elements and exhausts, are in place and fully functional.

### **0.1.8.1.2**

In the event of malfunctions, stop the machine immediately and lock out. Have any defects rectified immediately.

## **0.1.8.2 Special work in conjunction with utilization of the machine and maintenance and repairs during operation; disposal of parts and consumables**

### **0.1.8.2.1**

Observe the adjusting, maintenance and inspection activities and intervals set out in the operating instructions, except where:

A: Warning light/ gauge or indicator calls for immediate action.

B: Adverse conditions necessitate more frequent servicing.

Observe information on the replacement of parts and equipment. These activities may be executed by skilled personnel only.

### **0.1.8.2.2**

If the machine is completely shut down for maintenance and repair work, it must be secured against inadvertent starting by:

- Switching off the engine and removing the ignition key.
- Implementing the lockout procedure.
- Attaching a warning sign to the control panel door

### **0.1.8.2.3**

Carry out maintenance and repair work only if the machine is positioned on stable and level ground and has been secured against inadvertent movement and buckling.

### **0.1.8.2.4**

Never allow unqualified personnel to attempt to remove or replace any part of the machine, or anyone to remove large or heavy components without adequate lifting tackle.

To avoid the risk of accidents, individual parts and large assemblies being moved for replacement purposes should be carefully attached to lifting tackle and secured.

Use only suitable and technically adequate lifting gear.

Never work or stand under suspended loads

## **0.1.8.2.5**

Falling from and/or onto a POWERSCREEN machine can cause injury or even death.

Do not climb on the machine.  
Never use machine parts as a climbing aid.

For carrying out overhead assembly work always use specially designed or otherwise safety-oriented ladders and working platforms.

Always use the walkway/platforms provided or a safe and secure platform approved by the regional safety enforcing authority.

Always use an EN/ANSI approved safety harness when reaching any points 7ft (2m) or more above the ground level.

Keep all handles, steps, handrails, platforms, landings and ladders free from dirt, oil, snow and ice.

## **0.1.8.2.6**

The fastening of loads and the instructing of crane operators should be entrusted to experienced persons only. The marshaller giving the instructions must be within sight or sound of the operator.

## **0.1.8.2.7**

After cleaning, examine all fuel, lubricant, and hydraulic fluid lines for leaks, loose connections, chafe marks and damage. Any defects found must be rectified without delay.

## **0.1.8.2.8**

Any safety devices removed for set-up, maintenance or repair purposes must be refitted and checked immediately upon completion of the maintenance and repair work.

## **0.1.8.2.9**

Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with Powerscreen equipment includes such items as oil, fuel, coolant, filters and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain or into any water source.

Ensure that all consumables and replaced parts are disposed of safely and with minimum environmental impact.

## **0.1.8.2.10**

A raised part of the machine can fall causing serious injuries or death.

Always fit a safety support strut if any part of the machine must be raised for any reason.

Never work under unsupported equipment.

Never work alone.



## **0.1.8.2.11**

Diesel fuel is highly flammable.

Never remove the filler cap, or refuel, with the engine running.

Never add gasoline or any other fuel mixes to diesel because of increased fire or explosion risks.

Do not smoke or carry out maintenance on the fuel system near naked lights or sources of sparks, such as welding equipment.

## **0.1.8.2.12**

Using unauthorised structures i.e. walkways, platforms etc in the vicinity of a POWERSCREEN machine is very dangerous and could lead to serious injury or even death through falling and/or entanglement with the machine.

Do not use any unauthorised structures.

## **0.1.8.2.13**

In-running nip points can cause serious injury or even death.

Do not reach into an unguarded machine.

Your arm could be pulled in and amputated.

Lockout machine before opening guard doors

## 0.1.9 Warning of special dangers

### 0.1.9.1 Electric energy

#### 0.1.9.1.1

Use only original fuses with the specified current rating. Switch off the machine immediately if trouble occurs in the electrical system.

#### 0.1.9.1.2

When working with the machine/plant, maintain a safe distance from overhead electric lines. If work is to be carried out close to overhead lines, the working equipment must be kept well away from them. Caution, danger! Check out the prescribed safety distances.

#### 0.1.9.1.3

If your machine comes into contact with a live wire:

- Warn others against approaching and touching the machine.

- Have the live wire de-energized.

#### 0.1.9.1.4

Work on the electrical system or equipment may only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such an electrician and in accordance with applicable electrical engineering rules.

#### 0.1.9.1.5

If provided for in the regulations, the power supply to parts of machines and plants, on which inspection, maintenance and repair work is to be carried out must be cut off.

Before starting any work, check the de energized parts for the the presence of power and ground or short-circuit them in addition to insulating adjacent live parts and elements.

#### 0.1.9.1.6

The electrical equipment of the machine is to be inspected and checked at regular intervals.

Defects such as loose connections or scorched or otherwise damaged cables must be rectified immediately.

#### 0.1.9.1.7

Necessary work on live parts and elements must be carried out only in the presence of a second person, who can cut off the power supply in case of danger by actuating the emergency shut off or main power switch. Secure the working area with a red-and-white safety chain and a warning sign. Use insulated tools only.

### **0.1.9.1.8**

Before starting work on high-voltage assemblies and after cutting out the power supply, the feeder cable must be grounded and components such as capacitors short-circuited with a grounding rod.

### **0.1.9.1.9**

These machines are wired on negative earth.

Always observe correct polarity.

Always disconnect battery leads before carrying out any maintenance to the electrical system.

The battery contains sulphuric acid, an electrolyte which can cause severe burns and produce explosive gases.

Avoid contact with the skin, eyes or clothing.

## **0.1.9.2 Gas, dust, steam and smoke**

### **0.1.9.2.1**

Always operate internal combustion engines and fuel operated heating systems only out of doors or in a well ventilated area. Before starting the machine in enclosed premises, make sure that there is sufficient ventilation.

Observe the regulations in force at the respective site.

Dust found on the machine or produced during work on the machine should be removed by extraction, not by blowing.

Dust waste should be dampened, placed in a sealed container and marked, to ensure safe disposal.

### **0.1.9.2.2**

Carry out welding, flame-cutting and grinding work on the machine/plant only if this has been expressly authorised, as there may be a risk of explosion and fire.

### **0.1.9.2.3**

Before carrying out welding, flame cutting and grinding operations, clean the machine and its surroundings from dust and other inflammable substances and make sure that the premises are adequately ventilated (as there may be a risk of explosion).

## 0.1.9.3 Hydraulic and pneumatic equipment

### 0.1.9.3.1

Work on hydraulic equipment may be carried out only by persons having special knowledge and experience in hydraulic systems.

### 0.1.9.3.2

Check all lines, hoses and screwed connections regularly for leaks and obvious damage. Repair damage immediately. Splashed oil may cause injury and fire.

### 0.1.9.3.3

Depressurise all system sections and pressure pipes (hydraulic system, compressed-air system) to be removed in accordance with the specific instructions for the unit concerned before carrying out any repair work.

### 0.1.9.3.4

Hydraulic and compressed-air lines must be laid and fitted properly. Ensure that no connections are interchanged. The fittings, lengths and quality of the hoses must comply with the technical requirements.

### 0.1.9.3.5

Always practice extreme cleanliness when servicing hydraulic components.

### 0.1.9.3.6

Hydraulic fluid under pressure can penetrate the skin causing serious injury.

If fluid is injected under the skin, it must be surgically removed or gangrene will result.

Always relieve pressure from the hydraulic system before carrying out any kind of maintenance or adjustment.

Always use a piece of cardboard to check for leaks. Do not use your hand.

Get medical help immediately.

## 0.1.10 Transporting and towing recommissioning

### 0.1.10.1

The machine must be towed, loaded and transported only in accordance with the operating instructions.

### 0.1.10.2

For towing the machine, observe the prescribed transport position, admissible speed and itinerary.

### 0.1.10.3

Use only appropriate means of transport and lifting gear of adequate capacity.

### 0.1.10.4

The recommissioning procedure must be strictly in accordance with the operating instructions.

### 0.1.10.5

Before starting work or travelling with the machine, check that the braking, signalling and lighting systems are fully functional.

### 0.1.10.6

Before setting the machine in motion always check that the accessories have been safely stowed away.

### 0.1.10.7

When travelling on public roads, ways and places, always observe the valid traffic regulations and, if necessary, ensure beforehand that the machine is in a condition compatible with these regulations.

### 0.1.10.8

In conditions of poor visibility and after dark, always switch on the lighting system.

## **0.1.10.9**

When crossing underpasses, bridges and tunnels or when passing under overhead lines always make sure that there is sufficient clearance.

Use safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.

## **0.1.10.10**

Never travel across slopes; always keep the working equipment and the load close to the ground, especially when travelling downhill.

## **0.1.10.11**

On sloping terrain, always adapt your travelling speed to the relevant ground conditions.

Never change to a lower gear on a slope. Always change gear before reaching a slope.


## **0.1.10.12**

Explosive separation of a tyre and rim parts can cause injury or death.

Do not attempt to mount a tyre unless you have the proper equipment and experience to perform the job.

Always maintain the correct pressure. Do not inflate the tyres above the recommended pressure. Never weld or heat wheel and tyre assembly. The heat can cause an increase in air pressure resulting in a tyre explosion. Welding can structurally weaken or deform the wheel. When inflating tyres, use a clip-on chuck and extension hose long enough to allow you to stand to one side and not in front or over the assembly.

## 0.1.11 Position of emergency stops





## 0.1.12 Machine Safety hazard decals

Decal reference numbers listed on this and the proceeding pages.

| OLD STYLE - 253 | NEW ANSI - 1500  | NEW ISO - 1500 |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
|-----------------|--|----------------|--------------------|-----------|-------------|-------------|-------------|--------------|-------------|--------------|-------------|--------------|--------------|---------------|--------------|---|---------|--------------------|-----------|-------------|-------------|-------------|--------------|-------------|--------------|-------------|--------------|--------------|---------------|--------------|
|                 | <table border="1"> <thead> <tr> <th>LINE VOLTAGE</th> <th>REQUIRED CLEARANCE</th> </tr> </thead> <tbody> <tr> <td>0 - 50 kv</td> <td>10ft (3.0m)</td> </tr> <tr> <td>50 - 200 kv</td> <td>15ft (4.6m)</td> </tr> <tr> <td>200 - 350 kv</td> <td>20ft (6.1m)</td> </tr> <tr> <td>350 - 500 kv</td> <td>25ft (7.5m)</td> </tr> <tr> <td>500 - 750 kv</td> <td>35ft (10.7m)</td> </tr> <tr> <td>750 - 1000 kv</td> <td>40ft (12.2m)</td> </tr> </tbody> </table> <p>1500-A0</p> | LINE VOLTAGE   | REQUIRED CLEARANCE | 0 - 50 kv | 10ft (3.0m) | 50 - 200 kv | 15ft (4.6m) | 200 - 350 kv | 20ft (6.1m) | 350 - 500 kv | 25ft (7.5m) | 500 - 750 kv | 35ft (10.7m) | 750 - 1000 kv | 40ft (12.2m) | <table border="1"> <thead> <tr> <th>VOLTAGE</th> <th>REQUIRED CLEARANCE</th> </tr> </thead> <tbody> <tr> <td>0 - 50 kv</td> <td>10ft (3.0m)</td> </tr> <tr> <td>50 - 200 kv</td> <td>15ft (4.6m)</td> </tr> <tr> <td>200 - 350 kv</td> <td>20ft (6.1m)</td> </tr> <tr> <td>350 - 500 kv</td> <td>25ft (7.5m)</td> </tr> <tr> <td>500 - 750 kv</td> <td>35ft (10.7m)</td> </tr> <tr> <td>750 - 1000 kv</td> <td>40ft (12.2m)</td> </tr> </tbody> </table> <p>1500-I0</p> | VOLTAGE | REQUIRED CLEARANCE | 0 - 50 kv | 10ft (3.0m) | 50 - 200 kv | 15ft (4.6m) | 200 - 350 kv | 20ft (6.1m) | 350 - 500 kv | 25ft (7.5m) | 500 - 750 kv | 35ft (10.7m) | 750 - 1000 kv | 40ft (12.2m) |
| LINE VOLTAGE    | REQUIRED CLEARANCE   |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 0 - 50 kv       | 10ft (3.0m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 50 - 200 kv     | 15ft (4.6m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 200 - 350 kv    | 20ft (6.1m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 350 - 500 kv    | 25ft (7.5m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 500 - 750 kv    | 35ft (10.7m)   |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 750 - 1000 kv   | 40ft (12.2m)   |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| VOLTAGE         | REQUIRED CLEARANCE   |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 0 - 50 kv       | 10ft (3.0m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 50 - 200 kv     | 15ft (4.6m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 200 - 350 kv    | 20ft (6.1m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 350 - 500 kv    | 25ft (7.5m)  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 500 - 750 kv    | 35ft (10.7m)   |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
| 750 - 1000 kv   | 40ft (12.2m)   |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |
|                 |  |                |                    |           |             |             |             |              |             |              |             |              |              |               |              |   |         |                    |           |             |             |             |              |             |              |             |              |              |               |              |

## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 316   | NEW ANSI - 1503  | NEW ISO - 1503   |
|---|--|--|
|  <p><b>WARNING</b></p> <p>Read and understand operator's manual and safety signs before using or maintaining machine.</p> <p>If you do not understand the information in the manuals consult your supervisor, the owner, or the manufacturer.</p> <p>316</p> |  <p><b>WARNING</b></p> <p>Improper operation or maintenance can result in serious injury or death.</p>  <p>Read and understand operator's manual and safety signs before using or maintaining machine. If you do not understand the information in the manuals, consult your supervisor, the owner or the manufacturer.</p> <p>1503-A0</p>  |   <p>1503-IO</p>    |
| OLD STYLE - 317   | NEW ANSI - 1504  | NEW ISO - 1504   |
|  <p><b>DANGER</b></p> <p><b>SKIN INJECTION HAZARD</b><br/>Use a piece of cardboard to check for hydraulic hose leaks. <b>DO NOT USE YOUR HAND.</b> If fluid is injected under the skin, it can cause gangrene. Get medical help immediately.</p>           |  <p><b>DANGER</b></p> <p><b>INJECTION HAZARD</b><br/>Escaping fluid under pressure can penetrate skin, causing serious injury.</p>  <p>Relieve pressure before disconnecting hydraulic lines. Keep away from leaks and pin holes. Use a piece of cardboard to search for leaks. Do not use hand. If fluid is injected under the skin, get medical help immediately.</p> <p>1504-A0</p> |   <p>1504-IO</p> |

## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 409 | NEW ANSI - 1506 | NEW ISO - 1506 |
|-----------------|-----------------|----------------|
|                 |                 |                |
| OLD STYLE - 410 | NEW ANSI - 1507 | NEW ISO - 1507 |
|                 |                 |                |

## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 426  | NEW ANSI - 1508   | NEW ISO - 1508   |
|--|---|--|
|  <p><b>WARNING</b></p> <p><b>FALLING HAZARD</b><br/>Do not climb onto moving or working machinery. You could fall and be seriously injured. <b>SWITCH OFF, LOCKOUT and TAGOUT</b> machine. Always use a suitable lifting platform before attempting any maintenance work, above 2 meters(6'6").</p> <p>426</p>  |  <p><b>WARNING</b></p> <p><b>FALL HAZARD</b><br/>Falling from this machine can result in serious injury or even death.</p> <p> </p> <p><b>DO NOT</b> climb on machine. Use a suitable lifting platform to service the machine.</p> <p>1508-A0</p>  |  <p> </p> <p>1508-I0</p>  |
| OLD STYLE - 427  | NEW ANSI - 1509   | NEW ISO - 1509   |
|  <p><b>WARNING</b></p> <p><b>PRIOR TO TRANSPORT</b></p> <ol style="list-style-type: none"> <li>(1) Check tyre pressures.</li> <li>(2) Check wheel nut torque.</li> <li>(3) Connect and check braking system.</li> <li>(4) Recheck wheel nut torque every 150 miles (200Km).</li> </ol> <p>Refer to Operator manual for correct tyre pressures and torque values.</p> <p>427</p> |  <p><b>WARNING</b></p> <p>Vehicle control can be affected by improper setup of vehicle.</p> <p><b>PRIOR TO TRANSPORT</b></p> <ol style="list-style-type: none"> <li>(1)  Check tyre pressures.</li> <li>(2)  Check wheel nut torque. Recheck wheel nut torque every 150 miles (200 km).</li> <li>(3)  Connect and check braking system.</li> </ol> <p>Refer to operators manual to correct tyre pressures and torque values.</p> <p>1509-A0</p> |  <p></p> <ol style="list-style-type: none"> <li>(1) </li> <li>(2)  Nm<br/>150 miles (200 km)</li> <li>(3) </li> </ol> <p></p> <p>1509-I0</p> |

## 0.1.12 Machine Safety hazard decals






| OLD STYLE - 562   | NEW ANSI - 1511   | NEW ISO - 1511  |
|---|---|---|
|   |   |   |
| OLD STYLE - 902   | NEW ANSI - 1512   | NEW ISO - 1512  |
|  |  |  |

## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 903   | NEW ANSI - 1513   | NEW ISO - 1513  |
|---|---|---|
|   |   |   |
| OLD STYLE - 905   | NEW ANSI - 1514   | NEW ISO - 1514  |
|  |  |  |



## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 907   | NEW ANSI - 1515  | NEW ISO - 1515   |
|---|--|--|
|  <p>907</p> |  <p>1515-I0</p>  |  <p>1515-A0</p>  |
| OLD STYLE - NONE  | NEW ANSI - 1520  | NEW ISO - 1520   |
|   |  <p>1520-I0</p> |  <p>1520-A0</p> |

## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 917   | NEW ANSI - 1521   | NEW ISO - 1521  |
|---|---|---|
|   |   |   |
| OLD STYLE - 918   | NEW ANSI - 1522   | NEW ISO - 1522  |
|  |  |  |















## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 919  | NEW ANSI - 1523  | NEW ISO - 1523   |
|--|--|--|
|  <p><b>WARNING</b></p> <p><b>CRUSH HAZARD</b><br/>SERIOUS INJURY or DEATH can result if struck by falling material from screenbox.<br/>Do not stand on walkway while machine is in operation.<br/>SWITCH OFF, LOCKOUT and TAGOUT machine before climbing on to walkway.</p> <p>919</p>  |  <p><b>WARNING</b></p> <p><b>FLYING MATERIAL HAZARD</b><br/>SERIOUS INJURY or DEATH can result if struck by material.</p>  <p>Platform is for maintenance and servicing only. DO NOT stand on walkway while machine is in operation. SWITCH OFF and LOCKOUT machine before maintaining or servicing.</p> <p>1523-A0</p>   |   <p>1523-10</p>    |
| OLD STYLE - 920  | NEW ANSI - 1524  | NEW ISO - 1524   |
|  <p><b>WARNING</b></p> <p><b>INHALATION HAZARD</b><br/>Death, serious injury, or delayed lung disease could result from breathing hazardous dusts that can be generated when certain hazardous materials (such as rocks, minerals sand or other substances) are crushed, screened, or conveyed with this equipment.<br/>Whenever dusts are generated by the operation of this equipment, determine if respiratory protection is needed and then only use approved respiratory protection as required by Federal, State, and Local safety and health regulations.</p> <p>920</p> |  <p><b>WARNING</b></p> <p><b>INHALATION HAZARD</b><br/>Death, serious injury or delayed lung disease may result from breathing hazardous dust.</p>  <p>Use dust suppression or dust collection equipment to minimize the dust exposure during operation of this machine.<br/>Use approved respiratory protection to avoid inhalation of dusts, when required by Federal, State and local safety health regulations. Contact your employer to establish whether these regulations require that you use respiratory protection.</p> <p>1524-A0</p> |   <p>1524-I0</p> |


## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - 1144   | NEW ANSI - 1525   | NEW ISO - 1525  |
|--|---|---|
|  |   |   |
| OLD STYLE - NONE   | NEW ANSI - 1528   | NEW ISO - 1528  |
|  |  |  |


## 0.1.12 Machine Safety hazard decals - CONTINUED

| OLD STYLE - NONE | NEW ANSI - 1530   | NEW ISO - 1530   |
|------------------|---|--|
|                  |  <p><b>WARNING</b></p> <p></p> <p><b>EXPLOSION HAZARD</b><br/>May cause severe injury or death due to ignition of explosive gases.</p> <p></p> <p>Keep welding sparks away from the battery area.<br/>Remove battery if required.</p> <p>1530-A0</p> |  <p></p> <p></p> <p>1530-I0</p>     |
| OLD STYLE - NONE | NEW ANSI - 1531   | NEW ISO - 1531   |
|                  |  <p><b>WARNING</b></p> <p></p> <p><b>BURN HAZARD</b><br/>Contact with hot surfaces can result in serious injury or death.</p> <p></p> <p>KEEP CLEAR. Allow surfaces to cool before servicing.</p> <p>1531-A0</p>                                 |  <p></p> <p></p> <p>1531-I0</p> |

## 0.1.12 Machine Safety hazard decals - CONTINUED




## 0.1.13 Machine safety hazard locations - End view






## 0.1.13 Machine decal hazard locations - Front view



## 0.1.13 Machine decal hazard locations - Left hand side





## Contents

|        |  |   |
|--------|--|---|
| 1.1    | General information .....                | 2 |
| 1.2    | Nomenclature and technical data .....    | 3 |
| 1.2.1  | Feeder unit (A) .....                    | 5 |
| 1.2.2  | Screen unit (B) .....                    | 6 |
| 1.2.3  | Tail conveyor (C) .....                  | 6 |
| 1.2.4  | Mid Product Side conveyor (D) .....      | 6 |
| 1.2.5  | Fines conveyor (E) .....                 | 6 |
| 1.2.6  | Collection (F) .....                     | 6 |
| 1.2.7  | Oversize product side conveyor (G) ..... | 7 |
| 1.2.8  | Power unit (H) .....                     | 7 |
| 1.2.9  | Chassis (I) .....                        | 8 |
| 1.2.10 | Hydraulics (J) .....                     | 9 |

## 1.1 General information

### H5163

Machine : ..... Mobile screening machine  
Machine Serial Number ..... :  
Engine/Electric Motor Serial number : .....

### H5163R

Total weight (Belt Feeder) ..... : Approx 36, 500 kg

### H5163

Total weight (Incline) ..... : Approx 35,500kg (40.23 US Tons)  
..... ESTIMATED


Overall dimensions ..... : Refer designs in Section Appendix  
Weight of construction units ..... : Refer to pertinent data on the  
..... following pages.

Dimensions of construction units ..... : Refer to pertinent data on the  
..... following pages.

Finish Painted code

Colour shall be to traceable standards. .... : BLUE RAL 5201  
..... BLACK RAL 9005


## 1.2 H5163 Nomenclature and technical data



| <b>Id</b> | <b>Construction unit</b>     |
|-----------|------------------------------|
| A         | Feeder unit                  |
| B         | Screen unit                  |
| C         | Tail conveyor                |
| D         | Mid - Fines side conveyor    |
| E         | Fines side conveyor          |
| F         | Collection conveyor          |
| G         | Mid - Oversize side conveyor |
| H         | Powerunit / Engine           |
| I         | Chassis / Tracks             |
| J         | Hydraulics                   |

| <b>Component</b>       |
|------------------------|
| Feeder / Hopper        |
| Screen box / Mesh deck |

## 1.2 H5163R Nomenclature and technical data



| Id | Construction unit         |
|----|---------------------------|
| A  | Feeder unit               |
| B  | Screen unit               |
| C  | Tail conveyor             |
| D  | Mid - Fines side conveyor |
| E  | Fines side conveyor       |
| F  | Collection conveyor       |
| G  | Oversize side conveyor    |
| H  | Powerunit / Engine        |
| I  | Chassis / Tracks          |
| J  | Hydraulics                |

| Component              |
|------------------------|
| Feeder / Hopper        |
| Screen box / Mesh deck |

## 1.2.1 Feeder unit (A)

### H5163R

#### 1.2.1.1 Feed hopper (inclined)

Opening size.....5.23 m x 2.70m (17' x 8'10")  
Capacity.....4.33 m<sup>3</sup> (5.67 yds<sup>3</sup>).  
Feed in height.....2.68m (8'10")

#### 1.2.1.2 Feeder conveyor

Belt width..... 1300mm (51") wide 4-ply plain trough belt.

### H5163

#### 1.2.1.3 Feed hopper (inclined)

Opening size.....4.4m (14'5") long x 2.70m (8'-10") wide  
Capacity.....6.78 m<sup>3</sup> (8.87 yrd<sup>3</sup>)  
Feed in height (Side).....3.85m (12'-8")  
Feed in height.(Rear).....3.85m (12'-8")

#### 1.2.1.4 Feeder conveyor

Belt width..... 1300mm (51") wide 4-ply plain trough belt.

## 1.2.2 Screen unit (B)

### 1.2.2.1 Screenbox -

Width.....1.56m (5'2")  
Length.....4.88 m (16')  
Weight.....8000 Kg Approx  
Oval stroke adjustable.....Maximum 19 mm (3/4')  
Oval stroke angle adjustable.....From 30 - 60 degrees

## 1.2.3 Tail Conveyor (C)

### 1.2.3.1 H5163R

Belt width .....900 mm (36")  
Stockpile Height .....4.16m (13' 8")  
Degree of incline: .....24°

### 1.2.3.2 H5163

Belt width .....1200 mm (48")  
Stockpile Height .....4.52m (14' 10")  
Degree of incline: .....10-22°

## 1.2.4 Mid - Fines Side Conveyor (D)

Belt width.....800 mm (32")  
Stockpile Height.....4.46m (14' 8")

## 1.2.5 Fines (E)

Belt width.....800 mm (32")  
Stockpile Height.....4.46m (14' - 8")

## 1.2.6 Collection Conveyor (F)

Belt width.....1200 mm (48")

## 1.2.7 Oversize Side Conveyor (H5163R) (G) Mid - Oversize Side Conveyor (H5163) (G)

Belt width.....800 mm (32")

Stockpile Height.....4.68m (14'- 8")

## 1.2.8 Power unit (H)

### H5163R

#### 1.2.8.1 Engine

##### DIESEL ENGINE:STANDARD

CAT C4.4 ACERT - 4 Cylinder diesel engine developing 97kW (130 bhp) @2200 RPM

Flywheel pump1: X1A 5063/5041/5041

PTO pump1: X1A 5023/5023

|                               |                                   |
|-------------------------------|-----------------------------------|
| Feeder Motors:                | Danfoss OMSS125 (125cc/rev) 2 OFF |
| Oversize recir side conveyor: | Danfoss OMH 400 (400cc/rev)       |
| Mid overs tail conveyor:      | Danfoss OMT500 (500cc/rev)        |
| Mid fines tail conveyor:      | Danfoss OMH400 (400cc/rev)        |
| Collection Conveyor Motor:    | Danfoss OMT500 (500cc/rev)        |
| Fines side conveyor:          | Danfoss OMT500 (500cc/rev)        |
| Screen Motor:                 | Parker F12 93 (93cc/rev)          |

### H5163

##### DIESEL ENGINE:STANDARD

Standard diesel engine: 4 cylinder diesel engine developing 97kW (130 bhp) @ 2200rpm

Flywheel pump: 63cc/rev and 41cc/rev and 41cc/rev

PTO 'A' pump: ..... 23cc/rev each circuit

Feed conveyor motors: ..... 125cc/rev x 2 off

Oversize recir side conveyor:..... 400cc/rev

Mid overs tail conv: ..... 500cc/rev

Mid fines side conv: ..... 400cc/rev

Under screen conveyor: ..... 500cc/rev

Fines side conveyor motors: ..... 500cc/rev

Screen Motor: ..... 93cc/rev

## **Tank Capacities:**

Hydraulic tank: 576L (153 US Gal)

Diesel tank: 336 L (89 US Gal)

Refer to engine operation manual in Section Appendix.

## **1.2.8.2 Battery**

Type: 12 Volt, negative earth - 2 OFF

Cranking Power: 810 amps SAE

## **1.2.9 Chassis (I)**

### **1.2.9.1 Tracks**

Tractive effort: 20,830 daN

Gradability percentage: 61.3%

Gearbox ratio: 1:153

Hydraulic motor: Rexroth 90 cc/rev.

Approximate speed: 0.62 Km/hr (0.39 Mph)

Flow rate: 90.2Lpm (19.8gpm)



## 1.2.10 Hydraulics (J)

### 1.2.10.1 Hoses

| Type                                     | Diameter | Working pressure | Test pressure | Burst pressure |
|--|----------|------------------|---------------|----------------|
| 2 SN-K "Semperpac 1"<br>DIN 20022 Part 3 | 3/4"     | 3500 psi         | 7395 psi      | 14210 psi      |
| R1 AT<br>DIN 20022 Part 3                | 3/16"    | 3570 psi         | 8700 psi      | 14500 psi      |
|  | 1/4"     | 3210 psi         | 7830 psi      | 13050 psi      |
|  | 5/16"    | 3070 psi         | 7395 psi      | 12325 psi      |
|  | 3/8"     | 2570 psi         | 6307 psi      | 10440 psi      |
|  | 1/2"     | 2295 psi         | 5582 psi      | 9280 psi       |
|  | 5/8"     | 1855 psi         | 4567 psi      | 7540 psi       |
|  | 3/4"     | 1500 psi         | 3697 psi      | 6090 psi       |
|  | 1"       | 1255 psi         | 3045 psi      | 5075 psi       |
|  | 1 1/4"   | 900 psi          | 2175 psi      | 3625 psi       |
|  | 1 1/2"   | 715 psi          | 1740 psi      | 2900 psi       |
|  | 2"       | 570 psi          | 1392 psi      | 2320 psi       |
| R2 AT<br>DIN 20022 Part 4                | 3/16"    | 5930 psi         | 14355 psi     | 23925 psi      |
|  | 1/4"     | 5710 psi         | 13920 psi     | 23200 psi      |
|  | 5/16"    | 5000 psi         | 12180 psi     | 20300 psi      |
|  | 3/8"     | 4710 psi         | 11527 psi     | 19140 psi      |
|  | 1/2"     | 3930 psi         | 9570 psi      | 15950 psi      |
|  | 5/8"     | 3570 psi         | 8700 psi      | 14500 psi      |
|  | 3/4"     | 3070 psi         | 7395 psi      | 12325 psi      |
|  | 1"       | 2355 psi         | 5655 psi      | 9425 psi       |
|  | 1 1/4"   | 1785 psi         | 4350 psi      | 7250 psi       |
|  | 1 1/2"   | 1285 psi         | 3190 psi      | 5220 psi       |
|  | 2"       | 1140 psi         | 2827 psi      | 4640 psi       |



## Contents

|     |                          |   |
|-----|--------------------------|---|
| 2.1 | Introduction.....        | 2 |
| 2.2 | General Information..... | 2 |
| 2.3 | Designated use.....      | 3 |
| 2.4 | Screening materials..... | 3 |
| 2.5 | Copyright.....           | 4 |

## 2.1 Introduction

This instruction manual contains important information on how to operate the machine safely, properly and most efficiently. Observing these instructions helps to avoid danger, to reduce repair costs and downtimes and to increase the reliability and life of the machine.

The operating instructions must always be available wherever the machine is in use.

These operating instructions must be read and applied by any person in charge of and/ or working on the machine such as:

### **Operation**

including setting up, troubleshooting during the course of work, evacuation of production waste, care and disposal of fuels and consumables.

### **Maintenance**

(servicing, inspection, repair).

and/ or

### **Transport**

Follow all applicable safety regulations for accident prevention and environmental protection.

## 2.2 General information

The H5163 which you have now received has been manufactured, assembled and tested with the utmost care and was built with first class materials.

Close attention has been paid to all details in assembly, running tests and final inspection.

We are confident that you have received a machine which will give you every satisfaction over a long period.

To be assured of faultless operation we would ask you to carefully read the following paragraphs and give the required time and attention to essential maintenance, cleaning and inspection.

The machine is simple to operate, adjustments are easy to make and expert assistance is seldom required, provided that ordinary care is exercised in daily use.

The machine has been built in accordance with state-of-the-art standards and recognised safety rules. It is designed to be reliable, efficient and safe when used and maintained in accordance with the instructions given in this manual.

## 2.2 General information

Nevertheless, its use may constitute a risk to life and limb of the user or of third parties, or cause damage to the machine and to other material property.

## 2.3 Designated use

The machine is designed exclusively as a self-contained mobile unit for screening materials into various sizes.

The material is deposited by the operator into the feed hopper.

The variable speed feeder delivers the material at the desired rate evenly on to the screenbox, where it is split into separate grades.

In order to operate the machine optimally for the respective application, several different screen mesh decks may be installed. Depending on the installed number of screen mesh decks the machine is able to screen out material of up to three different sizes.

Using the H5163 for uses not specified in this manual or approved by Powerscreen, will result in a loss of the guarantee and the manufacturer/supplier cannot be held liable for any damage resulting from such use. The risk of such misuse lies entirely with the user.

## 2.4 Screening materials

Quarry Waste / Overburden  
Sand & Gravel  
Top Soil  
Coal  
Crushed Stone  
Recycling  
Demolition  
Compost

### NOTICE

**If you need to process any material with the H5163 machine which is not on the above list, contact your local POWERSCREEN Dealer or POWERSCREEN Aftersales Department for advice.**



**If you have any doubts about any aspect of the machine's capability or servicing procedures, you must consult your local POWERSCREEN Dealer or POWERSCREEN Aftersales Department.**

## 2.5 © Copyright Powerscreen 2008

The contents of this publication are the copyright of POWERSCREEN International Distribution Ltd. and may not be reproduced (even extracts), copied, distributed, altered, stored on electronic media, revealed to others or used for the purpose of competition, either partially or in its entirety unless permission is granted by Powerscreen - Engineering Manuals Dept.

In line with our policy of continuous development of our products we reserve the right to alter the specifications given in this manual regarding any product and / or part thereof without notice.

### **POWERSCREEN**

#### **International Distribution Ltd.**

Coalisland Road, Dungannon, Co.Tyrone,  
N.Ireland, BT71 4DR.

Telephone: ++44 (0) 28 8740701

Fax: ++44 (0) 28 87 71849

E-mail: [aftersales@powerscreen.com](mailto:aftersales@powerscreen.com)

## Contents

### 3.1 General Information

|                           |   |
|---------------------------|---|
| Left and right hand ..... | 3 |
| Front and rear .....      | 3 |

### 3.2 Machine components

|                                    |   |
|------------------------------------|---|
| <b>3.2.1 Feeder unit (A)</b> ..... | 4 |
|------------------------------------|---|

|  |   |
|--|---|
| <b>3.2.1.1 Apron feeder unit</b> ..... | 5 |
|--|---|

|                                    |   |
|------------------------------------|---|
| <b>3.2.1.2 Feeder hopper</b> ..... | 6 |
|------------------------------------|---|

#### 3.2.1.3 Feeder conveyor (A2)

|                              |   |
|------------------------------|---|
| Conveyor belt assembly ..... | 7 |
|------------------------------|---|

|                        |   |
|------------------------|---|
| Belt performance ..... | 8 |
|------------------------|---|

|                    |   |
|--------------------|---|
| Belt tension ..... | 9 |
|--------------------|---|

|                      |   |
|----------------------|---|
| Belt alignment ..... | 9 |
|----------------------|---|

|                     |   |
|---------------------|---|
| Belt slippage ..... | 9 |
|---------------------|---|

|                                    |    |
|------------------------------------|----|
| <b>3.2.2 Screen unit (B)</b> ..... | 10 |
|------------------------------------|----|

|                                      |    |
|--------------------------------------|----|
| <b>3.2.3 Tail conveyor (C)</b> ..... | 11 |
|--------------------------------------|----|

|                                   |    |
|-----------------------------------|----|
| Tail conveyor belt assembly ..... | 11 |
|-----------------------------------|----|

|                        |    |
|------------------------|----|
| Belt performance ..... | 12 |
|------------------------|----|

|                    |    |
|--------------------|----|
| Belt tension ..... | 13 |
|--------------------|----|

|                      |    |
|----------------------|----|
| Belt alignment ..... | 13 |
|----------------------|----|

|                     |    |
|---------------------|----|
| Belt slippage ..... | 13 |
|---------------------|----|

|  |    |
|--|----|
| <b>3.2.4 Mid - Fines side conveyor (D)</b> ..... | 14 |
|--|----|

|                                   |    |
|-----------------------------------|----|
| Side conveyor belt assembly ..... | 14 |
|-----------------------------------|----|

|                        |    |
|------------------------|----|
| Belt performance ..... | 15 |
|------------------------|----|

|                    |    |
|--------------------|----|
| Belt tension ..... | 16 |
|--------------------|----|

|                      |    |
|----------------------|----|
| Belt alignment ..... | 16 |
|----------------------|----|

|                     |    |
|---------------------|----|
| Belt slippage ..... | 16 |
|---------------------|----|

|  |    |
|--|----|
| <b>3.2.5 Fines - Side conveyor (E)</b> ..... | 17 |
|--|----|

|                                   |    |
|-----------------------------------|----|
| Side conveyor belt assembly ..... | 17 |
|-----------------------------------|----|

|                        |    |
|------------------------|----|
| Belt performance ..... | 18 |
|------------------------|----|

|                    |    |
|--------------------|----|
| Belt tension ..... | 19 |
|--------------------|----|

|                      |    |
|----------------------|----|
| Belt alignment ..... | 19 |
|----------------------|----|

|                     |    |
|---------------------|----|
| Belt slippage ..... | 19 |
|---------------------|----|

## Contents



|                |  |    |
|----------------|--|----|
| <b>3.2.6</b>   | <b>Collection conveyors (F)</b> .....                      | 20 |
|                | Collection conveyor belt assembly                          |    |
|                | Belt performance .....                                     | 21 |
|                | Belt tension .....   | 22 |
|                | Belt alignment .....                                       | 22 |
|                | Belt slippage .....  | 22 |
| <b>3.2.7</b>   | <b>Mid Oversize / Oversize side conveyor LHS (G)</b>       |    |
|                | Conveyor belt assembly .....                               | 23 |
|                | Belt performance .....                                     | 24 |
|                | Belt tension .....   | 25 |
|                | Belt alignment .....                                       | 25 |
|                | Belt slippage .....  | 25 |
| <b>3.2.8</b>   | <b>Power unit</b> .....                                    | 26 |
| 3.2.8.1        | Control panel (H1) .....                                   | 28 |
| 3.2.8.2        | Control valve units (H2) .....                             | 30 |
|                | Auxiliary control bank .....                               | 32 |
|                | Drive control bank .....                                   | 33 |
|                | Variable speed flow control .....                          | 34 |
| <b>3.2.8.3</b> | <b>Hand trottle (H3)</b> .....                             | 36 |
| 3.2.8.4        | Control valves (H4 Lhs) .....                              | 37 |
| 3.2.8.5        | Control valves (H5 Rhs) .....                              | 38 |
| 3.2.8.6        | Control valves (H6 Rhs) .....                              | 39 |
| <b>3.2.8.7</b> | <b>Radio control (H7)</b> .....                            | 40 |
| 3.2.8.8        | Remote control (H8) (conjunction with radio control) ..... | 42 |
| <b>3.2.9</b>   | <b>Hopper wing plate (H9)</b>                              |    |
| 3.2.9.1        | Return line filter .....                                   | 45 |
| <b>3.2.10</b>  | <b>Hydraulic system</b>                                    |    |
| 3.2.10.1       | Return line filter .....                                   | 46 |
| <b>3.2.11</b>  | <b>Chassis</b> .....                                       | 47 |



## 3.1 General Information


### Left and Right hand

When using this handbook, at all times the right and the left hand references are viewed from the rear end of the machine.



### Front and Rear

When using this handbook, at all times the rear of the machine is situated at the feed end.






## 3.2 Construction units

### 3.2.1 Feeder unit (A)

The feeder unit consists of 2 main components:

- A1 Feed hopper
- A2 Feeder conveyor







## 3.2.2 Construction units

### 3.2.1.1 Feeder unit (A)

The apron feeder unit consists of 2 main components:

- A1 Feed hopper
- A2 Feeder conveyor




### 3.2.1.2 Feedhopper (A1)

#### H5163 R

The feed hopper capacity is 4.33 cu.m (5.67 cu.yds,) with clamping arrangement for rubber skirts and is manufactured from hardox steel plate.

The wide belt allows steep hopper sides to minimise material build-up.




#### H5163

The feed hopper capacity is 6.78 cu.m (8.87 cu.yds,) with clamping arrangement for rubber skirts and is manufactured from hardox steel replaceable plate panels.

The feed hopper is hydraulic folding for transport and fitted with impact protection bars.

The wide belt allows steep hopper sides to minimise material build-up.




## 3.2.1.3 Feeder conveyor (A2)

The feeder conveyor is attached to the H5163's hopper unit for the purpose of feeding material from the feed hopper on to the screen.

The feeder belt is driven by two hydraulic motors with two variable speed gearbox adjustment to determine the feed rate.

Belt tension adjustments are made outside of the guard doors.



**H5163 - A2**


### Conveyor belt assembly

The feeder conveyor belt assembly on all POWERSCREEN H5163 machines consists of :

- 1 Drive drum
- 2 Tail drum
- 3 Conveyor belting
- 4 Guide rollers
- 5 Impact bars
- 6 Impact rollers
- 7 Belt scrapers
- 8 Guarding
- 9 Viewing apertures



**H5163 - INCLNE - A2**



## **Belt performance**

All conveyor belts and drum lagging on POWERSCREEN machines are made to the highest standards and are tough and durable.

However these are consumable items and will need to be replaced through normal wear and tear.

Spliced belts are less effective than vulcanized and have an increased tendency to slip.

Also a belt which has been adjusted to its maximum must be replaced with a new belt.

Worn lagging must also be replaced.

The correct procedure for changing a belt/lagging is to contact your local POWERSCREEN dealer who will either carry out the work himself or get it carried out by personnel trained in this field.

To ensure optimum performance and safety, the conveyor(s) must be:

1. Cleaned on a daily basis or more frequently depending on the application.

(For details contact your local POWERSCREEN dealer.)

2. Checked for cuts, tears, rips or any other physical damage.

3. Tensioned properly.

4. Kept in alignment.

## Belt Tension

The belt will normally have to be tensioned a number of times during the belt's lifetime due to the natural stretching of the belt.

It is very important that the conveyor belt is tensioned evenly and to the correct level, not too tight and not too loose.

A loose belt can cause slippage, resulting in reduced throughput.

An over-tight belt can damage drum bearings, resulting in increased downtime.

Correct tension is obtained when no slippage occurs during normal use.

## Belt alignment

For safe, proper and efficient operation of the machine, it is important that conveyor belts are properly aligned.

The belt alignment can be checked without removing any guard by looking through the viewing apertures.

The conveyor belts are aligned by adjusting the drum adjusters.

Reasons for the conveyor belts not running in alignment:

1. Machine not perfectly levelled.
2. Faulty belt tension.
3. Faulty position of the drums.

Solution refer to section "troubleshooting"

## Belt Slippage

So long as the described maintenance procedures have been properly observed, your machine should not experience belt slippage.

Slippage occurs when the drum turns and the belt does not move.


Slippage can occur for a number of reasons including:

1. Incorrectly tensioned belts
2. Worn belts.
3. Ineffective lagging.
4. Too much load on the belt.
5. Rollers cannot rotate freely.


Solution refer to Section "troubleshooting"

## 3.2.2 Screen unit (B)

The screen unit is attached at the end of the H5163's feed conveyor where it screens raw material into different sizes.



**REFER TO CEDARAPIDS  
MANUAL FOR FURTHER DETAILS.**





## 3.2.3 Tail conveyor (C)



The tail conveyor is attached to the H5163's front chassis for the purpose of feeding the oversize material from the screen.

The tail conveyor belt is driven by a hydraulic motor.


### Conveyor belt assembly

The conveyor belt assemblies on all POWERSCREEN machines consists of:

- 1 Drive drum
- 2 Tail drum
- 3 Conveyor belting
- 4 Side rollers
- 5 Center rollers
- 6 Return disc rollers
- 7 Belt scrapers
- 8 Guarding
- 9 Viewing apertures



**H5163**



**H5163 R**

## **Belt performance**

All conveyor belts and drum lagging on POWERSCREEN machines are made to the highest standards and are tough and durable.

However these are consumable items and will need to be replaced through normal wear and tear.

Spliced belts are less effective than vulcanized and have an increased tendency to slip.

Also a belt which has been adjusted to its maximum must be replaced with a new belt.

Worn lagging must also be replaced.

The correct procedure for changing a belt/lagging is to contact your local POWERSCREEN dealer who will either carry out the work himself or get it carried out by personnel trained in this field.

To ensure optimum performance and safety, the conveyor(s) must be:

1. Cleaned on a daily basis or more frequently depending on the application.  
(For details contact your local POWERSCREEN dealer.)

2. Checked for cuts, tears, rips or any other physical damage.

3. Tensioned properly.

4. Kept in alignment.

## Belt Tension

The belt will normally have to be tensioned a number of times during the belt's lifetime due to the natural stretching of the belt.

It is very important that the conveyor belt is tensioned evenly and to the correct level, not too tight and not too loose.

A loose belt can cause slippage, resulting in reduced throughput.

An over-tight belt can damage drum bearings, resulting in increased downtime.

Correct tension is obtained when no slippage occurs during normal use.

## Belt alignment

For safe, proper and efficient operation of the machine, it is important that conveyor belts are properly aligned.

The belt alignment can be checked without removing any guard by looking through the viewing apertures.

The conveyor belts are aligned by adjusting the drum adjusters.

Reasons for the conveyor belts not running in alignment:

1. Machine not perfectly levelled.
2. Faulty belt tension.
3. Faulty position of the drums.

Solution refer to section troubleshooting.

## Belt Slippage

So long as the described maintenance procedures have been properly observed, your machine should not experience belt slippage.

Slippage occurs when the drum turns and the belt does not move.

Slippage can occur for a number of reasons including:

1. Incorrectly tensioned belts
2. Worn belts.
3. Ineffective lagging.
4. Too much load on the belt.
5. Rollers cannot rotate freely.

Solution refer to section troubleshooting

## 3.2.4 MID - FINES Side conveyor (D)




The MID - FINES side conveyor is attached to the H5163's front RHS chassis for the purpose of discharging material at 90° degrees to the screen unit. It is hydraulically opened and closed.

The side conveyor belt is driven by a hydraulic motor. For transport purposes the side conveyor is pinned into position. It includes a feedboot and incorporates head drum guarding. Belt tension adjustments can be made external to the guard doors.

### Conveyor belt assembly

The conveyor belt assemblies on all POWERSCREEN machines consists of:

- 1 Drive drum
- 2 Tail drum
- 3 Conveyor belting
- 4 Side rollers
- 5 Center rollers
- 6 Return disc rollers
- 7 Belt scrapers
- 8 Guarding
- 9 Viewing apertures



## Belt performance

All conveyor belts and drum lagging on POWERSCREEN machines are made to the highest standards and are tough and durable.

However these are consumable items and will need to be replaced through normal wear and tear.

Spliced belts are less effective than vulcanized and have an increased tendency to slip.

Also a belt which has been adjusted to its maximum must be replaced with a new belt.

Worn lagging must also be replaced.

The correct procedure for changing a belt/lagging is to contact your local POWERSCREEN dealer who will either carry out the work himself or get it carried out by personnel trained in this field.

To ensure optimum performance and safety, the conveyor(s) must be:


1. Cleaned on a daily basis or more frequently depending on the application.

(For details contact your local POWERSCREEN dealer.)

2. Checked for cuts, tears, rips or any other physical damage.

3. Tensioned properly.

4. Kept in alignment.



## Belt Tension

The belt will normally have to be tensioned a number of times during the belt's lifetime due to the natural stretching of the belt.

It is very important that the conveyor belt is tensioned evenly and to the correct level, not too tight and not too loose.

A loose belt can cause slippage, resulting in reduced throughput.

An over-tight belt can damage drum bearings, resulting in increased downtime.

Correct tension is obtained when no slippage occurs during normal use.

## Belt alignment

For safe, proper and efficient operation of the machine, it is important that conveyor belts are properly aligned.

The belt alignment can be checked without removing any guard by looking through the viewing apertures.

The conveyor belts are aligned by adjusting the drum adjusters.

Reasons for the conveyor belts not running in alignment:

1. Machine not perfectly levelled.
2. Faulty belt tension.
3. Faulty position of the drums.

Solution refer to section "Operating instructions," "troubleshooting."

## Belt Slippage

So long as the described maintenance procedures have been properly observed, your machine should not experience belt slippage.

Slippage occurs when the drum turns and the belt does not move.

Slippage can occur for a number of reasons including:

1. Incorrectly tensioned belts
2. Worn belts.
3. Ineffective lagging.
4. Too much load on the belt.
5. Rollers cannot rotate freely.

Solution refer to Section "Operating instructions," "Troubleshooting."



## 3.2.5 Fines - Side conveyor (E)

The side conveyor is attached to the H5163's rear RHS chassis for the purpose of discharging material at 90° degrees to the screen unit. It is hydraulically opened and closed.

The side conveyor belt is driven by a hydraulic motor.

For transport purposes the side conveyor is pinned into position (**P**).

It includes a feedboot and incorporates head drum guarding.  
Belt tension adjustments can be made external to the guard doors.



## Belt performance

All conveyor belts and drum lagging on POWERSCREEN machines are made to the highest standards and are tough and durable.

However these are consumable items and will need to be replaced through normal wear and tear.

Spliced belts are less effective than vulcanized and have an increased tendency to slip.

Also a belt which has been adjusted to its maximum must be replaced with a new belt.

Worn lagging must also be replaced.

The correct procedure for changing a belt/lagging is to contact your local POWERSCREEN dealer who will either carry out the work himself or get it carried out by personnel trained in this field.

To ensure optimum performance and safety, the conveyor(s) must be:

1. Cleaned on a daily basis or more frequently depending on the application.  
(For details contact your local POWERSCREEN dealer.)

2. Checked for cuts, tears, rips or any other physical damage.


3. Tensioned properly.

4. Kept in alignment.

## Conveyor belt assembly

The conveyor belt assemblies on all POWERSCREEN machines consists of:

- |   |                     |
|---|---------------------|
| 1 | Drive drum          |
| 2 | Tail drum           |
| 3 | Conveyor belting    |
| 4 | Side rollers        |
| 5 | Center rollers      |
| 6 | Return disc rollers |
| 7 | Belt scrapers       |
| 8 | Guarding            |
| 9 | Viewing apertures   |





## Belt Tension

The belt will normally have to be tensioned a number of times during the belt's lifetime due to the natural stretching of the belt.

It is very important that the conveyor belt is tensioned evenly and to the correct level, not too tight and not too loose.

A loose belt can cause slippage, resulting in reduced throughput.

An over-tight belt can damage drum bearings, resulting in increased downtime.

Correct tension is obtained when no slippage occurs during normal use.

## Belt alignment

For safe, proper and efficient operation of the machine, it is important that conveyor belts are properly aligned.

The belt alignment can be checked without removing any guard by looking through the viewing apertures.

The conveyor belts are aligned by adjusting the drum adjusters.

Reasons for the conveyor belts not running in alignment:

1. Machine not perfectly levelled.
2. Faulty belt tension.
3. Faulty position of the drums.

Solution refer to section troubleshooting

## Belt Slippage

So long as the described maintenance procedures have been properly observed, your machine should not experience belt slippage.

Slippage occurs when the drum turns and the belt does not move.

Slippage can occur for a number of reasons including:

1. Incorrectly tensioned belts
2. Worn belts.
3. Ineffective lagging.
4. Too much load on the belt.
5. Rollers cannot rotate freely.



Solution refer to Section Troubleshooting

## 3.2.6 Collection conveyor (F)

The collection conveyor is attached to the H5163's chassis for the purpose of feeding material from the screen unit to the fines side conveyor.

The collection conveyor belt is driven by a hydraulic motor.

Belt tension adjustments can be made outside of the guard doors.



**Collection conveyor (F)**

## Belt performance

All conveyor belts and drum lagging on POWERSCREEN machines are made to the highest standards and are tough and durable.

However these are consumable items and will need to be replaced through normal wear and tear.

Spliced belts are less effective than vulcanized and have an increased tendency to slip.

Also a belt which has been adjusted to its maximum must be replaced with a new belt.

Worn lagging must also be replaced.

The correct procedure for changing a belt/lagging is to contact your local POWERSCREEN dealer who will either carry out the work himself or get it carried out by personnel trained in this field.

To ensure optimum performance and safety, the conveyor(s) must be:

1. Cleaned on a daily basis or more frequently depending on the application.  
(For details contact your local POWERSCREEN dealer.)

2. Checked for cuts, tears, rips or any other physical damage.


3. Tensioned properly.

4. Kept in alignment.

## Collection conveyor belt assembly

The conveyor belt assemblies on all POWERSCREEN machines consists of :

- 1 Drive drum
- 2 Tail drum
- 3 Conveyor belting
- 4 Side Rollers
- 5 Center rollers
- 6 Return rollers
- 7 Belt scrapers
- 8 Guarding
- 9 Viewing apertures



## Belt Tension

The belt will normally have to be tensioned a number of times during the belt's lifetime due to the natural stretching of the belt.

It is very important that the conveyor belt is tensioned evenly and to the correct level, not too tight and not too loose.

A loose belt can cause slippage, resulting in reduced throughput.

An over-tight belt can damage drum bearings, resulting in increased downtime.

Correct tension is obtained when no slippage occurs during normal use.

## Belt alignment

For safe, proper and efficient operation of the machine, it is important that conveyor belts are properly aligned.

The belt alignment can be checked without removing any guard by looking through the viewing apertures.

The conveyor belts are aligned by adjusting the drum adjusters.

Reasons for the conveyor belts not running in alignment:

1. Machine not perfectly levelled.
2. Faulty belt tension.
3. Faulty position of the drums.

Solution refer to section Troubleshooting

## Belt Slippage

So long as the described maintenance procedures have been properly observed, your machine should not experience belt slippage.

Slippage occurs when the drum turns and the belt does not move.

Slippage can occur for a number of reasons including:

1. Incorrectly tensioned belts
2. Worn belts.
3. Ineffective lagging.
4. Too much load on the belt.
5. Rollers cannot rotate freely.



Solution refer to Section Troubleshooting

## 3.2.7 LHS Side Conveyor (G)

The OVERSIZE conveyor is attached to the H5163's chassis LHS front side for the purpose of discharging oversized material from the machine.

The conveyor belt is driven by a hydraulic motor.

Belt tension adjustments can be made outside of the guard doors.



## Belt performance

All conveyor belts and drum lagging on POWERSCREEN machines are made to the highest standards and are tough and durable.

However these are consumable items and will need to be replaced through normal wear and tear.

Spliced belts are less effective than vulcanized and have an increased tendency to slip.

Also a belt which has been adjusted to its maximum must be replaced with a new belt.

Worn lagging must also be replaced.

The correct procedure for changing a belt/lagging is to contact your local POWERSCREEN dealer who will either carry out the work himself or get it carried out by personnel trained in this field.

To ensure optimum performance and safety, the conveyor(s) must be:

1. Cleaned on a daily basis or more frequently depending on the application.

(For details contact your local POWERSCREEN dealer.)

2. Checked for cuts, tears, rips or any other physical damage.


3. Tensioned properly.

4. Kept in alignment.

## Oversize Conveyor belt assembly

The conveyor belt assemblies on all POWERSCREEN machines consists of:

- 1 Drive drum
- 2 Tail drum
- 3 Conveyor belting
- 4 Side rollers
- 5 Center rollers
- 6 Return disc rollers
- 7 Belt scrapers
- 8 Guarding
- 9 Viewing apertures



## Belt Tension

The belt will normally have to be tensioned a number of times during the belt's lifetime due to the natural stretching of the belt.

It is very important that the conveyor belt is tensioned evenly and to the correct level, not too tight and not too loose.

A loose belt can cause slippage, resulting in reduced throughput.

An over-tight belt can damage drum bearings, resulting in increased downtime.

Correct tension is obtained when no slippage occurs during normal use.

## Belt alignment

For safe, proper and efficient operation of the machine, it is important that conveyor belts are properly aligned.

The belt alignment can be checked without removing any guard by looking through the viewing apertures.

The conveyor belts are aligned by adjusting the drum adjusters.

Reasons for the conveyor belts not running in alignment:

1. Machine not perfectly levelled.
2. Faulty belt tension.
3. Faulty position of the drums.

Solution refer to section Troubleshooting

## Belt Slippage

So long as the described maintenance procedures have been properly observed, your machine should not experience belt slippage.

Slippage occurs when the drum turns and the belt does not move.

Slippage can occur for a number of reasons including:



1. Incorrectly tensioned belts
2. Worn belts.
3. Ineffective lagging.
4. Too much load on the belt.
5. Rollers cannot rotate freely.

Solution refer to Section Troubleshooting

## 3.2.8 Power unit (H)

The power unit (H) is attached at the chassis (I) of the H5163, under the feeder conveyor (A.)

The power unit is completely enclosed, sound suppressed and lockable.





## 3.2.8 Power unit (H)

The H5163 has NINE control units.

|                        |      |
|------------------------|------|
| The control panel      | (H1) |
| The control valve unit | (H2) |
| Hand throttle          | (H3) |
| Tail                   | (H4) |
| Jacking Legs           | (H5) |
| Mid-fines valve unit   | (H6) |
| Radio control          | (H7) |
| Remote control         | (H8) |





The control panel H1, control valve unit H2 and hand throttle H3 are situated at the powerunit on the right hand side of the machine.

The control valves (H4) are situated on the LHS of the machine.

The control valves (H5+ H6) are situated on the RHS of the machine.

The controls (H7 & H8) are independant control units.

They control the movement of the tracks.  
They are described in more detail at the end of this section.



## 3.2.8.1 Control Panel (H1) Main control panel warning lights



### Battery Charging Warning Light

This light should illuminate when the key switch is turned to the On position. As soon as the engine starts it should go out. If it fails to illuminate when the key is turned on, or if it illuminates when the engine is running, it indicates that there is a fault in the charging circuit. Stop the engine and have the circuit checked.



### Engine Run light

This light will only illuminate when the key is turned to the ON position and will remain on at all times. If it goes out then an E-Stop has been pressed and the engine will shut down immediately.



### Fuel On Light

This light should illuminate when the engine starts and will remain on at all times. It will go out when the engine has been shut down.



### Air breather Restriction Warning Light.

This light should illuminate if a problem occurs in the air breather system. If the AIR FILTER OVERRIDE link on the main control panel is in, then the light will remain on continuously until the fault has been repaired. IF the AIR FILTER OVERRIDE link is out and it continues to receive a fault signal, the light will remain on for 30 minutes. After 30 minutes the engine will shut down but the light will remain on until the fault has been repaired.



### Hydraulic Oil level Warning Light

This light will only illuminate if the hydraulic oil level is low. The engine will shut down 5 seconds after the fault has been detected.

### 3.2.8.1 Control Panel (H1) Main control panel warning lights (Continued)



#### **E-Stop Activated Light**

This light will only illuminate when an E-Stop has been pressed. This will immediately shut down the engine. If the light is flashing after shut down, this indicates that the manual tracking doglead E-Stop has been pressed. If the light remains on constantly then another E-Stop has been pressed.



#### **Engine Pre-heat Indicator Light**

This light only illuminates when the pre-heat button is operated during start up.



#### **Fuel Contamination Warning Light**

This light will only illuminate if a problem occurs in the fuel system, such as water contamination. The engine will shut down 1 second after the fault has been detected.

#### **Hour Clock**

This records the number of hours that the engine has been running.

#### **Key Start Switch**


This is used to start the engine when required.

## ENGINE PRE-HEAT

If an engine pre-heat sequence was installed to the control panel during manufacture, it will be either automatic or manual.

If it is automatic then the pre-heat light (H) will illuminate when the key is turned to the start position (C). The engine will crank automatically once the pre-heat operation has been completed and the light will go out.

If manual pre-heat has been fitted then the light will illuminate when the key is turned to the pre-heat position (G). The light will extinguish after the pre-heat operation has been completed and the key can be turned to the start position (C) to crank the engine.



**C**



**H. Engine Pre-Heater Indicator Light**

## 3.2.8.2 Control valve unit (H2)

The levers of the drive control unit, are for the purpose of driving the machine.

- a) Auxiliary control bank
- b) Drive control bank


with FOUR additional control valves,

- c) Variable speed flow control valve for feeder conveyor

- d) Variable speed flow control valve for tail conveyor.

- e) Variable speed flow control valve for the collection conveyor.


- f) Variable speed flow control valve for the fines conveyor is on the fines conveyor.



Note: that all control valve levers are labelled on the machine.

### Symbols for the levers

In the manual the following symbols are used to show the position (up, neutral, down) of the levers.




## a) Auxiliary control bank

The auxiliary control bank performs:

- (1) Feeder angle  
RAISE: A  
LOWER: a
- (2) Feeder Conveyor  
RAISE B  
LOWER b
- (3) Fines Conveyor  
FOLD IN C  
FOLD OUT c


Auxiliary control



Neutral

**H2 a**


Auxiliary control



Raising

**H2 a**

Auxiliary control



Lowering

**H2 a**

## b) Drive control bank

The drive control bank performs the following function:

Engaging/stopping the drive

### (4) Feeder Conveyor

Drive: +  
Stop: NEUTRAL  
Engage: Tracks  
Stop: NEUTRAL

### (5) Tail conveyor



Drive: +  
Stop: NEUTRAL

### (6) Screenbox + Fines Conveyor

Drive: +  
Stop: NEUTRAL

### (7) Collection

Drive: +  
Stop: NEUTRAL  
Engage: Tracks  
Stop: NEUTRAL



## H5163

### (8) Mid Oversize / Mid fines

Drive: +  
Stop: NEUTRAL

## H5163R

### (8) Oversize / Mid fines

Drive: +  
Stop: NEUTRAL




Conveyors controlled by this lever are equipped with a 10 second start delay and warning siren

### c) Variable speed flow control

The variable speed flow control valve (c,) controls the speed of feeder conveyor when the conveyor control valve is engaged (**H2b - lever 4**).

Rotating clockwise (R,) decreases the speed of the conveyor.

Rotating counter clockwise (L,) increases the speed of the conveyor.



### d) Variable speed flow control

The variable speed flow control valve (d,) controls the speed of tail conveyor when the tail conveyor control valve is engaged (**H2b - lever 5**).

Rotating clockwise (R,) decreases the speed of the side conveyor.

Rotating counter clockwise (L,) increases the speed of the side conveyor.




## e) Variable speed flow control

The variable speed flow control valve (e,) controls the speed of collection conveyor when the conveyor control valve is engaged (**H2b - lever 7**).

Rotating clockwise (R,) decreases the speed of the conveyor.

Rotating counter clockwise (L,) increases the speed of the conveyor.



## 3.2.8.3 Hand Throttle (H3)


The hand throttle has two functions:

Increasing/decreasing the engine speed.

**(1)** Hand throttle (HT,)

**Increase power:**  
pull to right of the operator.

**Decrease power:**  
pull to left of the operator.



## 3.2.8.4 Control valve unit (H4)

The OVERSIZE side and tail conveyor control valve unit (H4) is situated on the LEFT hand side, at the front of the machine.

**(E1)** Tail conveyor head section  
RAISE: D  
LOWER: d

**(E2)** Oversize side conveyor  
RAISE: E  
LOWER: e


### f) Variable speed flow control

The variable speed flow control valve (e,) controls the speed of oversize conveyor when the conveyor control valve is engaged (5).

Rotating clockwise (R,) decreases the speed of the conveyor.

Rotating counter clockwise (L,) increases the speed of the conveyor.

**H4**




Neutral


**(E1) (E2)**

**H4**

**Folding  
(D) (E)**




**H4**



**(d) (e)**

**Unfolding**



**H4 f**

**H4 E**

**H4**



## 3.2.8.5 Control valve unit (H5)

The jacking legs control valve unit (H5) is situated on the right hand side, at the centre of the machine.

### (D1) LH Rear Jacking Leg

RAISING: A

LOWERING: a

### (D2) RH Rear Jacking Leg

RAISING: B

LOWERING: b

### (D3) RH Front Jacking Leg





RAISING: C

LOWERING: c

### (D4) LH Front Jacking Leg

RAISING: D

LOWERING: d



## 3.2.8.6 Control valve unit (H6)

The mid fines conveyor control valve unit (H6) is situated on the left hand side, at the front of the machine.

### (C1) Mid Fines Conveyor

RAISE : A





LOWER: a

### g) Variable speed flow control

The variable speed flow control valve (g,) controls the speed of mid fines conveyor when the conveyor control valve is engaged (6).

Rotating clockwise (R,) decreases the speed of the conveyor.

Rotating counter clockwise (L,) increases the speed of the conveyor.



## 3.2.8.7 Radio Control (H7)

The radio control unit consists of a receiver and a hand-held, battery powered radio control unit. It is fitted to track machines as an option.



To operate the radio control push;

(1) move the two track levers of the drive control **(H2 - Lever 4 + 7)** down fully.

(2) To start remote tracking disconnect the manual handset from the machine and press any button on the transmitter.

After the 7 second delay has elapsed the track directional switches become active.


Find the explanation of the hand-held radio control unit on the following pages.





## 3.2 Construction units

### 3.2.8.7 Radio Control (H7)



To start remote tracking disconnect the manual handset from the machine and press any button on the transmitter.

After the 7 second delay has elapsed the track directional switches become active.

## 3.2.8.8 Remote control (H8) (in conjunction with the radio control)

The remote control unit consists of a hand-held direct lead.

To operate the radio control;

(1) attach the hand remote control unit (RU,) to socket (S.)




(2) push the two levers of the drive control (H2,) **(H2 - Lever 4 + 7)** down fully.

(3) Push the “tracks” button (1,) to the left, auxiliary/tracks

Find the explanation of the hand-held remote control unit on the following pages.

### NOTICE

The remote control is only used to operate the tracks.  
It performs no other operation.





## Hand-held remote control unit (H8)

### Tracking using the Hand-held remote control unit (H7)


Ensure that the doglead is connected to the machine, and that the doglead E-Stop is not processed.

Start the engine as per setup procedure.

Switch the Tracking On / Off switch on the Doglead handset to the "Track" position.

At this point the siren should sound for 7 seconds and the tracking beacon will flash.


The machine can now be tracked using the controls on the doglead as shown opposite.



### Hand-held remote control unit (H8)

#### NOTICE



When the remote control unit is not in use, the function buttons must remain in the neutral position. Before tracking machine the safety chapter instructions in **MUST** be read.



## 3.2.8.9 Control valve unit (H9)


The control valve unit (H9) performs the FOLDING, UNFOLDING, OF THE HOPPER WING PLATES

- (1) Hopper back folding  
RAISE: A  
LOWER: a
- (2) Hopper RH folding  
RAISE: B  
LOWER: b
- (3) Hopper LH folding  
RAISE: B  
LOWER: b




## 3.2.10 Hydraulic system

- A Hydraulic Oil Level Indicator
- C Filler Cap
- D Drain Plug
- E Suction Filters
- F Return Line Filter



### 3.2.10.1 Return Line Filter (F)

- A Blockage Indicator
- B Filter Element
- C Filter Housing
- D Retaining Bolts
- E Seal ring





## 3.2.11 Chassis (I)

The chassis is sturdily constructed and supports LH side conveyor, hopper, RH side conveyor, tail conveyor, collection conveyor, powerunit and screen unit.

In working position the machine is supported by:

1. One set of tracks





## Contents

|       |                                     |   |
|-------|-------------------------------------|---|
| 4.1   | Safety information .....            | 2 |
| 4.2.1 | Track machine .....                 | 6 |
| 4.2.2 | Wheel machine (Roll-in Bogie) ..... | 7 |

## 4.2.1 Track machine

### PROCEDURE




**Prior to towing the H5163 on the highway, the machine must be put in towing position in accordance with Section "Shut-off."**

1. Observe all safety warnings.
2. Remove all loose materials such as rocks from the machine.
3. Put the machine in the transport position (Refer to Section "Shut-off").
4. The machine should be loaded onto the low loader, with the conveyors and hopper in their folded position.



## HAZARDS

|   |  |
|---|--|
| <b>1520 / 1513 ISO<br/>1520 / 1513 ANSI</b> | <b>WEAR PERSONAL PROTECTIVE EQUIPMENT</b><br>Refer this Section, safety information for relevant warning.                      |
| <b>1506 ISO<br/>1506 ANSI</b>               | <b>CRUSHING HAZARD</b><br>Refer this Section, safety information for relevant warning.   |
| <b>1503 ISO<br/>1503 ANSI</b>               | <b>READ OPERATOR'S MANUAL</b><br>Refer this Section, safety information for relevant warning.                                  |
| <b>1502 ISO<br/>1502 ANSI</b>               | <b>ENTANGLEMENT MANUAL</b><br>Refer this Section, safety information for relevant warning.                                     |
| <b>1509 ISO<br/>1509 ANSI</b>               | <b>PRIOR TO TRANSPORT HAZARD</b><br>Refer to Safety Chapter Section - <b>Machine Safety Hazard Decals</b> for relevant warning |



**Transport Position - H5163R shown**  
**See Appendix Chapter for further additional Dimensions**



## 4.2.2 Wheel machine (Roll-in Bogie Option)

### PROCEDURE



**Prior to towing the H5163 on the highway, the machine must be put in towing position in accordance with Section “Shut-off.”**

1. Observe all safety warnings.
2. Remove all loose materials such as rocks from the machine.
3. Put the machine in the transport position (Refer to Section “Shut- off.”)
4. Attach lights to the front of the machine.
5. Connect and check lights.
6. Check tyre pressure. (Refer to Section “Maintenance.”)
7. Check wheel nut torque (Refer to Section “Maintenance.”)
8. Connect and check braking system.
9. Re-check wheel nut torque every 150 miles (200km).



## HAZARDS

|   |  |
|---|--|
| <b>1520 / 1513 ISO</b><br><b>1520 / 1513 ANSI</b> | <b>WEAR PERSONAL PROTECTIVE EQUIPMENT</b><br>Refer this Section, safety information for relevant warning.                      |
| <b>1506 ISO</b><br><b>1506 ANSI</b>               | <b>CRUSHING HAZARD</b><br>Refer this Section, safety information for relevant warning.   |
| <b>1503 ISO</b><br><b>1503 ANSI</b>               | <b>READ OPERATOR’S MANUAL</b><br>Refer this Section, safety information for relevant warning.                                  |
| <b>1502 ISO</b><br><b>1502 ANSI</b>               | <b>ENTANGLEMENT MANUAL</b><br>Refer this Section, safety information for relevant warning.                                     |
| <b>1509 ISO</b><br><b>1509 ANSI</b>               | <b>PRIOR TO TRANSPORT HAZARD</b><br>Refer to Safety Chapter Section - <b>Machine Safety Hazard Decals</b> for relevant warning |



## Contents

|         |  |    |
|---------|--|----|
| 5.1     | General information .....                        | 2  |
| 5.2     | Dimensions, required space and weight .....      | 2  |
| 5.3     | Measures before set up .....                     | 2  |
| 5.4     | Measures after long term standstill .....        | 3  |
| 5.5     | Machine set up .....                             | 4  |
| 5.5.1   | Starting the engine .....                        | 5  |
| 5.5.2   | Removing machine from the low loader .....       | 7  |
| 5.5.2.1 | Radio control .....                              | 7  |
| 5.5.2.2 | Remote control .....                             | 8  |
| 5.5.3   | Prior installation .....                         | 10 |
| 5.5.4   | Opening out FINES side conveyor (H2) .....       | 11 |
| 5.5.5   | Opening out MID - FINES side conveyor (H6) ..... | 14 |
| 5.5.6   | Opening out LHS side conveyor (H4) .....         | 16 |
| 5.5.7   | Preparing the walkways .....                     | 18 |
| 5.5.8   | Opening out tail conveyor .....                  | 20 |
| 5.5.9   | Screenbox Perpetration .....                     | 22 |

## 5.1 General information

We recommend that the assembly installation work of the H5163 be carried out by the POWERSCREEN customer service department.

The manufacturer/ supplier will not be liable for damage caused by improper assembly/ installation.

## 5.2 Dimensions, required space and weight

### Dimensions

Refer to Appendix chapter.

### Required space

Refer to Appendix chapter.

### Weight

Refer to Technical Information chapter.

## 5.3 Measures before set up

1. Ensure all guards are fully secured in correct/closed position.

2. Remove all loose items from the machine by untying the securing ropes.

When setting up the H5163 pay particular attention to the following points:

1. The H5163 must be placed on solid ground capable of carrying the machine's weight.

2. Before detaching the H5163 from the prime mover, it is important that the chosen site is level.

Level the worksite foundation with the loading shovel.

3. Level the H5163 with a precision spirit level.

4. Do not position the machine above ground level, eg. on blocks etc.

## 5.4 Measures after long term standstill

Check tracks before transporting or moving the machine.

### **NOTICE**

**Prior to putting into operation perform daily (10 hour) maintenance schedule.**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**

Refer this Section, safety information for relevant warning.

## 5.5 Machine set up

For dusty conditions some account should be taken of the prevailing wind to minimize the possibility of dust entering the air intake.

When setting up the H5163 ensure that enough space is available around the machine/ plant to enable easy set up, servicing and repair work.

Machines arranged before and after the H5163 will have to be placed accordingly.

The general arrangement diagram giving you the basic information of the H5163 including measurements and weight is provided in Section Appendix.

Before setting up the H5163 this section and all of the previous sections must be read, understood and observed.

Any work on and with the machine must be executed by reliable, authorised personnel only. Statutory minimum age limits must be observed.

## 5.5.1 Starting the engine



**All control levers must be in the neutral (non-operational) position. Do not start engine without the above mentioned warning lights being illuminated.**

### PROCEDURE

1. Observe all safety warnings.
2. Turn ignition key to position "I".
3. The following warning lights on the control panel will illuminate:
  - (A) - Charge lamp
  - (B) - Oil pressure lamp
  - (E) - Machine run lamp



## HAZARDS

**1520 / 1513 ISO**  
**1520 / 1513 ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.


**1532 ISO**  
**1532 ANSI**


**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO**  
**1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.





4. Turn ignition key to position “” the safety siren will start, hold in this position until the engine cranks after 7 seconds.

5. Release ignition key immediately after the engine starts.  
The key will return to run position, “”.



**If the warning lights fail to extinguish stop the engine and detect the fault before using the machine.**







## 5.5.2 RADIO CONTROL

The radio control unit consists of a receiver and a hand held, battery powered radio control unit. It is only fitted as an optional extra.

To operate the radio control

- 1 Observe all safety warnings
- 2 Start the Engine
- 3 Ensure that both levers on the DRIVE control bank are engaged. That is, **the drive FEEDER conveyor control lever and the drive COLLECTION / FINES control lever are in the down position, all other levers should be in the neutral position (G2 - LEVERS 4+7 - LOWER)**
- 4 Remove handset from cradle and press any button . The siren will sound for 7 seconds and the beacon will operate. After which the radio control handset is active
- 5 The handset controls are as follows



**Figure 5.5.2**

## 5.5.2.2 Remote control



All control levers must be in the neutral (non-operational) position.

Refer to Section Design & Function for complete specification on radio/remote control units before attempting the following procedures.

### PROCEDURE

1. Observe all safety warnings.
2. Prepare the low loading trailer, for removing the HORIZON on tracks.
3. Remove the dummy plug and insert the remote control unit (**RU**), into it's socket (**S**) at the rear of the HORIZON.
4. Start the engine. (Refer this Section, relevant paragraph.)



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**

Refer this Section, safety information for relevant warning.



## 5.5.2.2 Remote control - CONTINUED



CAUTION


Ensure all personnel are clear from the machine

5. Using the remote control unit (H9,)

**To operate the remote control push;**

(1) move the track levers down, to activate the tracks

**(H2 - Levers 4 and 7)**



## 5.6.3 Prior Installation

### PROCEDURE

1. Observe all safety warnings.
2. Remove items, such as side conveyor skirting etc. from the conveyors.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**  
Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information  
for relevant warning.

## 5.5.4 Opening out the FINES side conveyor



**All control levers must be in the neutral (non-operational) position.**



**The Fines Side Conveyor control valve unit (H2) is situated in the powerunit on the RHS, at the rear of the machine.**

1. Observe all safety warnings.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.


**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.



Neutral

H2a




## 5.5.4 Opening out the FINES side conveyor - Continued

2. Start the engine.  
(Refer relevant paragraph, section 5.5.1).



3. Remove all transport pins  
and transport stays from the side  
conveyor.

4. Move the Fines conveyor lever down  
to fold the conveyor out into working  
position. **(H2 - LEVER 3 - LOWER)**



## 5.5.4 Opening out the FINES side conveyor -Continued

5. Insert the working position pins  
1 off LH/RH.

## 5.5.5 Opening out the MID FINES side conveyor (H6)



All control levers must be in the neutral (non-operational) position.



## HAZARDS

1520 / 1513  
ISO  
1520 / 1513  
ANSI

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

1532 ISO  
1532 ANSI

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

1508 ISO  
1508 ANSI

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.


Neutral



H6

## PROCEDURE

1. Observe all safety warnings.
2. Start the engine.
3. Remove all transport pins (**P**) and transport stays (**TS**) from the side conveyor.




H6





4. Move the MID - FINES side conveyor lever down to fold out the conveyor (**H6 - LEVER LOWER**).
5. Insert the working position pins 1 off LH/RH.



## 5.5.6 Opening out the LHS conveyor



All control levers must be in the neutral (non-operational) position.



LHS conveyor on the H5163 is known as the MID-OVERSIZE, whereas on the H5163R it is known as the OVERSIZE conveyor.

### PROCEDURE

1. Observe all safety warnings.
2. Start the engine.
3. Remove all transport pins (P) and transport stays (TS) from the side conveyor.



## HAZARDS

1520 / 1513  
ISO  
1520 / 1513  
ANSI

### WEAR PERSONAL PROTECTIVE EQUIPMENT

Refer this Section, safety information for relevant warning.

1532 ISO  
1532 ANSI

### LOCKOUT AND TAGOUT

Refer this Section, safety information for relevant warning.


1508 ISO  
1508 ANSI

### FALL HAZARD

Refer this Section, safety information for relevant warning.

H4


Neutral



H4



4. Move the OVERSIZE side conveyor lever down to fold out the conveyor (**H2 - LEVER E2 LOWER**).
7. Insert the working position pins 1 off LH/RH.



## 5.5.7 Preparing the walkways

1. Observe all safety warnings.
2. Lower RH + LH (**P**) platforms and bolt onto mounting plates.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**  
Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information  
for relevant warning.


**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information  
for relevant warning.



## 5.5.7 Preparing the walkways - Continued

### 4. Attach side rails (SR) and hand rails (HR)



## 5.5.8 Opening out the Tail Conveyor



**All control levers must be in the neutral (non-operational) position.**

### PROCEDURE

The combined oversize side and tail conveyor control valve unit (H4) is situated on the left hand side, at the front of the machine.

1. Observe all safety warnings.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.


**1508 ISO  
1508 ANSI**

**FALL HAZARD**

Refer this Section, safety information for relevant warning.

**H4**

**Neutral**




**(E1) (E2)**




**H4**

2. Stop the machine and implement the LOCKOUT procedure.




## 5.7.8 Opening out the Tail Conveyor - Continued


3. With the aid of proper lifting equipment lift conveyor at position (C). Raise until in position. Fix adjusters and bolt into position as shown (A + B).



4. Start the engine (Refer to relevant paragraph).



5. Move up the tail conveyor lever until the conveyor is at the required angle (**H4 - Lever E1 - RAISE**).



6. Shut off ball valve at control lever.

## 5.5.9 Screenbox Preparation



**All control levers must be in the neutral (non-operational) position.**

### PROCEDURE

1. Rotate breaker bars (B) into position  
side deflector plate (D) into position.

### NOTICE

**For proper operation and maintenance - REFER to CEDERRAPIDS Instruction booklet.**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

### WEAR PERSONAL PROTECTIVE EQUIPMENT

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


### LOCKOUT AND TAGOUT

Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

### FALL HAZARD

Refer this Section, safety information for relevant warning.





## Contents

|                                       |    |
|---------------------------------------|----|
| 6.1 General information.....          | 2  |
| 6.2 Normal operation                  |    |
| 6.2.1 Putting into operation.....     | 3  |
| 6.2.2 Operating the system.....       | 7  |
| 6.2.3 Care and maintenance.....       | 9  |
| 6.3 Emergency Stop.....               | 12 |
| 6.4 Restart after emergency stop..... | 12 |

## 6.1 General information



The HORIZON may only be operated if the safety instructions provided in the previous chapters have been observed and the described procedures have been performed.

Operate the machine only if all protective and safety devices, such as removable safety devices, emergency shut-off equipment, sound-proofing elements and exhausts are in place, fully functional and properly maintained.


During operation, all sound baffles must be closed.

In the event the machine malfunctions for any reason, stop the machine and lock out immediately. Report the malfunction to the competent authority in charge.

DO NOT continue to operate the machine UNTIL the malfunction is corrected!



**ALWAYS WEAR A EN/ANSI approved HARD HAT AND FOOTWEAR WITH ADEQUATE TOE PROTECTION** when working in the vicinity of the machine and on the work site.



**KEEP AWAY FROM THE CONVEYOR BELTS,** where there is risk of serious injury or death due to rejected processed material and danger from other heavy machinery working in the area, unless you are a fully-trained operator engaged in collecting processed material.

## 6.2 Normal operation

### 6.2.1 Putting into operation

The levers of the drive control unit, are for the purpose of driving the machine.

- a) Auxiliary control bank
- b) Drive control bank

with FOUR additional control valves,

- c) Variable speed flow control valve for feeder conveyor
- d) Variable speed flow control valve for tail conveyor.
- e) Variable speed flow control valve for the collection conveyor.
- f) Variable speed flow control valve for the fines conveyor.

### PROCEDURE

Note: that all control valve levers are labelled on the machine.

1. Observe all safety warnings.
2. Start the engine  
(Refer Section Set-up).



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**  
Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information  
for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information  
for relevant warning.




## 6.2 Normal operation

### 6.2.1 Putting into operation - CONTINUED

3. Move up the TAIL lever, to start the TAIL conveyor

**(H2b - LEVER 5 - RAISE)**




H2b

Drive control

4. Move up the OVERSIZE / MID FINES conveyor lever to start the OVERSIZE / MID FINES conveyor.

**(H2b - LEVER 8 - RAISE)**




H2b

Drive control

5. Move up the SCREEN + FINES conveyor lever to drive the screen motor and to start the FINES conveyor.

**(H2b - LEVER 6 - RAISE)**



H2b


Drive control

## 6.2 Normal operation

### 6.2.1 Putting into operation - CONTINUED


7. Move up the COLLECTION lever to start the COLLECTION conveyor.

**(H2b - LEVER 7 - RAISE)**



8. Move up FEEDER lever to drive feeder conveyor.

**(H2b - LEVER 4 - RAISE)**



9. Set the MID FINES + TAIL conveyor speeds on the variable speed controls relative to material **(H2 - FLOW CONTROLS C+D )**.

10. Check that all conveyor belts are running in alignment.

If an adjustment is necessary refer to Section Maintenance.

11. Turn the control knobs of the variable speed flow control valves to level 2.

12. Fill up the feed hopper.

13. To obtain optimal feeder speed, turn the control knob of the variable speed flow control valve (**C**)

**counter clockwise:**

To increase the feeder speed.

**clockwise:**

To decrease the feeder speed.

14. Re-check that all conveyor belts are running in alignment.  
If an adjustment is necessary refer to Section 8, "Maintenance."  
Check that screenbox is running and is capable of screening.

15. Re-fill feed hopper.

16. To obtain optimal feeder speed, turn the control knob of the variable speed flow control valve (C):


**counter clockwise:**

To increase the feeder speed.

**clockwise:**

To decrease the feeder speed.

17. The machine is now adjusted for continuous operation.



## **6.2.2 Operating the system (Remote operation is optional)**

Only authorized personnel are permitted to operate this system.

Before operating any function by remote control the operator should have direct sight of the function and be fully aware of the consequences of operating the function.

It is the responsibility of the operator to ensure that the remote transmitter is only operated when it is safe to do so.

The operator must be familiar with the operation of the machine and must observe all safety procedures and warnings. Before starting the machine or operating any function the operator must be sure that it is safe to do so.

To operate the system manually the machine should be started as normal.

The hydraulic valve operating levers should be set to the function run position. At this point no function will operate. Press the push buttons on the control unit in the proper sequence to operate the machine.

A second press of any function button will turn the function off.

The shutdown sequence should be carried in the proper sequence to stop the machine.

## **6.2.2 Operating the system continued (Remote operation is optional)**

To operate the machine using the remote transmitter the machine should be started as normal.

The function levers should be set to the run position. At this point no function will operate. Before the function buttons can operate on the remote control the ON button on the transmitter has to be pressed twice within 2 seconds to arm the operating buttons. Press the operating buttons on the remote control transmitter to turn on the functions taking care that the buttons are operated in the proper sequence.

When the operating buttons are active the led on the transmitter will light when a button is pressed.

A second press of a function button will turn the function off. The shutdown should be carried out in the proper sequence to stop the machine. If no function is operated by the remote transmitter for 2 minutes the transmitter will turn off and the function buttons will not operate until the transmitter is rearmed.



## **6.2.3 Care and Maintenance (Remote operation is optional)**

The control unit should be located where it is protected from falling debris and water spray. The control unit does not require any maintenance.

The transmitter should be kept in a safe location and protected from falling debris and water contamination.

If the transmitter is being operated from a loader then it may be possible to clip or secure the transmitter to the loader sun visor or some other suitable fixture using the belt clip located on the rear of the transmitter housing. However if it is stored the transmitter should be protected from impact damage.

If any such damage occurs or the casing or buttons are visibly damaged or the transmitter has been tampered with or malfunctions in any way the transmitter should be disabled by removing the battery cover located at the rear of the unit and removing the batteries. The transmitter should be replaced or returned for examination.

## **Transmitter batteries (Remote operation is optional)**

### **Transmitter battery life depends on the amount of use of the transmitter.**

Low batteries are indicated by the led on the transmitter going dim when a button is operated and/or functions not turning on or off. When this happens the batteries should be replaced.

2 1.5 volt AAA alkaline batteries located in the rear of the transmitter casing power the transmitter. To replace the batteries: -

1. Undo the 3mm screw securing the battery compartment cover at the rear of the transmitter.
2. To remove raise the cover at the end adjacent to the belt clip on the transmitter, swing the cover out and lift off.
3. Remove exhausted batteries.
4. Fit 2 new AAA size alkaline batteries taking special care to ensure that the battery polarity symbols align with the corresponding symbols embossed on the base of the battery compartment. Incorrect polarity may damage the transmitter. Do not mix old and new batteries.
5. Refit the cover by engaging the small catches at the bottom edge of the cover with the slots on the lower edge of the battery compartment and then fold the cover towards the belt clip. Secure the cover with the 3mm screw

## Receiver Programming (Remote operation is optional)

The receiver is coded to the transmitter so that the transmitter can communicate with the receiver. Each transmitter has a unique code and if a transmitter or receiver is replaced the receiver has to be programmed to match the transmitter.

To program a receiver to a transmitter proceed as follows: -

1. Remove the cover from the control unit casing by unscrewing the 4 fixing screws. Ensure that "LD1" led is turned on. This led is situated on the top right side of the main circuit board and indicates that the receiver is supplied with power.
2. Locate the "prog I D" switch and the "prog" led situated above the 40 pin device on the main circuit board.
3. Set the "prog I D" switch to program position by moving the switch lever to the left position.
4. Locate the "program I D" push button situated to the right of the 40 pin device.
5. Press and release the "program I D" push button. The "prog" led will turn on.
6. Arm the transmitter if not already armed by operating the "ON" button twice within 2 seconds. Press and release any transmitter operating button. The "prog" led will turn off and the "valid signal" led (situated below the 40 pin device) will turn on while the transmitter button is being pressed.
7. Set the "prog I D" switch to the operating position by moving the switch lever to the right position. The programming is now completed.
8. Replace the lid on the control unit casing and secure with the 4 screws.

### NOTICE

**The receiver also has a block of 8 switches fitted beside "LD1" led. These switches are factory set and should not be adjusted.**

## 6.3 Emergency Stop



**In case of incident or trouble,  
you MUST follow the following  
procedure:**

1. Engage the nearest emergency stop.
2. Switch off the engine and remove the ignition key.
3. Implement the Lockout procedure.
4. Only when the machine is fully switched off, should an attempt be made to solve the problem.
5. Never work alone.

## 6.4 Restart after Emergency Stop

1. Ensure that the problem has been solved.
2. Ensure that all personnel are outside clear of the machine.
3. Ensure that all guards and safety devices are correctly fitted and fully functional.
4. Release all emergency stops.
5. Re-start the machine.  
(Refer to relevant paragraph).

## Contents

|       |  |   |
|-------|--|---|
| 7.1   | Shut-off.....                                      | 2 |
| 7.2   | Putting the machine in the transport position..... | 4 |
| 7.2.1 | Folding MID-FINES side conveyor for transport..... | 5 |
| 7.2.2 | Folding LHS side conveyor for transport.....       | 7 |
| 7.2.3 | Folding FINES side conveyor for transport.....     | 8 |
| 7.2.4 | Preparing the walkways for transport.....          | 9 |

## 7.1 Shut-off



**Empty HORIZON prior to shut-off.**

### PROCEDURE

1. Observe all safety warnings.

2. Stop the FEEDER conveyor.  
(H2-Lever 4 - Neutral).

3. Stop the SCREEN + FINES conveyor.  
(H2 - Lever 6 - neutral).



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**


**FALL HAZARD**

Refer this Section, safety information for relevant warning.




H2b

Drive control




H2b

Drive control




## 7.1 Shut-off - CONTINUED


4. Stop the COLLECTION conveyor (**H2 - Lever 7 - neutral**).



5. Stop the LHS and TRANSFER conveyor (**H2 - Lever 8 - neutral**).



6. Stop the TAIL/MID FINES conveyor (**H2 - Lever 5 - Neutral**).



7. Stop the engine.



## 7.2 Putting the machine in the transport position



**Shut-off the H5163 in accordance to Section “Shut-off,” prior to putting into transport position.**

### PROCEDURE

1. Observe all safety warnings.
2. Start the engine.  
(Refer to Section 5, “Set up.”)
3. Prepare the walkways
4. Prepare the transfer conveyor  
(slide back).
5. Prepare screenbox for transport.
6. Prepare FINES side conveyor for transport.
7. Prepare MID-FINES side conveyor for transport.
8. Prepare LHS side conveyor for transport.
9. Prepare tail conveyor for transport.

### NOTICE

**Tail drum adjusters must be slackened off before folding the tail conveyor**



## HAZARDS

|   |   |
|---|---|
| <b>1520 / 1513 ISO<br/>1520 / 1513 ANSI</b> | <b>WEAR PERSONAL PROTECTIVE EQUIPMENT</b><br>Refer this Section, safety information for relevant warning. |
| <b>1532 ISO<br/>1532 ANSI</b>               | <b>LOCKOUT AND TAGOUT</b><br>Refer this Section, safety information for relevant warning.                 |
| <b>1508 ISO<br/>1508 ANSI</b>               | <b>FALL HAZARD</b><br>Refer this Section, safety information for relevant warning.                        |
| <b>1513 ISO<br/>1513 ANSI</b>               | <b>HEARING HAZARD</b><br>Refer this Section, safety information for relevant warning.                     |
| <b>1503 ISO<br/>1503 ANSI</b>               | <b>READ AND UNDERSTAND MANUAL</b><br>Refer this Section, safety information for relevant warning.         |
| <b>1521 ISO<br/>1521 ANSI</b>               | <b>CRUSH HAZARD</b><br>Refer this Section, safety information for relevant warning.                       |
| <b>1522 ISO<br/>1522 ANSI</b>               | <b>AUTOMATIC STARTUP</b><br>Refer this Section, safety information for relevant warning.                  |
| <b>1523 ISO<br/>1523 ANSI</b>               | <b>CRUSH HAZARD</b><br>Refer this Section, safety information for relevant warning.                       |



## 7.2.1 Fold MID-FINES side conveyor for transport (H6)



**All control levers must be in the neutral (non-operational) position.**

### PROCEDURE

1. Observe all safety warnings.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**

Refer this Section, safety information for relevant warning.

**1513 ISO  
1513 ANSI**

**HEARING HAZARD**

Refer this Section, safety information for relevant warning.

**1503 ISO  
1503 ANSI**

**READ AND UNDERSTAND MANUAL**

Refer this Section, safety information for relevant warning.

**1521 ISO  
1521 ANSI**

**CRUSH HAZARD**

Refer this Section, safety information for relevant warning.

**1522 ISO  
1522 ANSI**

**AUTOMATIC STARTUP**

Refer this Section, safety information for relevant warning.


**1523 ISO  
1523 ANSI**

**CRUSH HAZARD**


Refer this Section, safety information for relevant warning.

## 7.2.1 Fold MID-FINES side conveyor for transport - Continued


2. Start the engine.



3. Remove the working pins 1 off Lhs/Rhs.



4. Move up the side conveyor lever to fold the side conveyor. **(H6-Lever 1).**



## 7.2.2 Fold LHS side conveyor for transport

The LHS side and tail conveyor control valve unit (H4) is situated on the LEFT hand side, at the front of the machine.



**All control levers must be in the neutral (non-operational) position.**

### PROCEDURE

1. Observe all safety warnings.
2. Start the engine.
3. Remove the working position pins 1 off LH/RH
4. Move up the LHS control lever to fold over the LHS conveyor.  
**(H4 - LEVER E2 - RAISE).**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.


**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.

## H4



## H4



## 7.2.3 Fold FINES-SIDE conveyor for transport

The Fines Side Conveyor control valve unit (G2) is situated in the auxilliary control bank in the Powerunit.



**All control levers must be in the neutral (non-operational) position.**

### PROCEDURE

1. Observe all safety warnings.
2. Start the engine.
3. Remove the working pins 1 off Lhs/ Rhs.
4. Move up the side conveyor lever to fold the side conveyor. **(H2 - LEVER 3 - RAISE INTO POSITION F).**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

### WEAR PERSONAL PROTECTIVE EQUIPMENT

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


### LOCKOUT AND TAGOUT

Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

### FALL HAZARD


Refer this Section, safety information for relevant warning.



**H2**

**(F)**

Neutral



## 7.2.4 Preparing the walkways for transport

### PROCEDURE

1. Observe all safety warnings.
2. Rotate handrails **(HR)** into position shown for transport.
3. Raise items marked **(C)** for transport.
4. Remove support handrails **(SHR)** for transport.
5. Remove ladder handrails **(LH)** for transport.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**

Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**


**LOCKOUT AND TAGOUT**

Refer this Section, safety information  
for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**

Refer this Section, safety information  
for relevant warning.





# Shutoff

H 5163R / H 5163

Issue 06 EG

Page 10



## 8.9.1 Fuel system

### 8.9.1.3 Empty the fuel filter water trap

#### PROCEDURE

1. Observe all safety warnings.
2. Unscrew the drain bung at the bottom of the water trap and allow the water to drain out.
3. Tighten the drain plug when pure diesel starts to come out.



**Diesel fuel is highly flammable.**

**Never remove filler cap or refuel, with the engine running.**

**Never add gasoline or any other fuel mixes to diesel because of increased fire or explosion risks.**

**Do not smoke or carry out maintenance on the fuel system near open flame or sources of sparks, such as welding equipment, etc..**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.



## 8.9.1 Fuel system

### 8.9.1.4 Change the fuel filter

#### PROCEDURE

1. Observe all safety warnings.
2. Unscrew the fuel filter.
3. Replace fuel filter.

#### NOTICE

**Fill up the new fuel filter with diesel.**

**This will make the restart of the machine easier.**

4. Tighten new fuel filter + o-ring



**Diesel fuel is highly flammable.**

**Never remove filler cap or refuel, with the engine running.**

**Never add gasoline or any other fuel mixes to diesel because of increased fire or explosion risks.**

**Do not smoke or carry out maintenance on the fuel system near open flame or sources of sparks, such as welding equipment, etc..**




## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**  
Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information  
for relevant warning.





## 8.9.2 Air Cleaner

### 8.9.2.1 Change outer air-cleaner element

#### PROCEDURE

#### NOTICE

**Always obey the air cleaner restriction indicator immediately if the control panel light illuminates. (Never attempt to clean and reuse an element.)**

**During normal service, the outer element (C) will require replacing only when the restriction indicator is illuminated.**

#### PROCEDURE

1. Observe safety warnings.
2. Release the three clips (A).
3. Remove cover (B).
4. Carefully remove outer filter (C).



**Do not run the engine with the dust cover (C) removed as this will result in dust ingress and subsequent engine failure.**

5. Lift the tabs on the outer edge and remove inner element (D).




## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



## 8.9.2 Air Cleaner

### 8.9.2.1 Change outer air-cleaner element - CONTINUED

6. Clean the inside of the air-cleaner casing using a damp, lint free cloth, paying particular attention to the element seals.
7. Replace the existing inner element (D).
8. Insert outer element (C) into place.
9. Re-fit cover (B).
10. Fasten the three clips (A).



**If the outer element has not been changed for 500 operating hours, a leak in the induction system must be suspected. Check that the air cleaner casing and hoses to the engine are not damaged. Check that all hose connections are airtight.**

## 8.9.2 Air cleaner

### 8.9.2.2 Clean the air cleaner



**Always obey the Air Cleaner restriction indicator immediately if the control panel light illuminates.  
(Never attempt to clean and reuse an element.)**

#### PROCEDURE

1. Observe safety warnings..
2. Release the three clips (A).
3. Remove cover (B).
4. Carefully remove outer filter (C).
5. Wipe the bowl clean.  
Remove oil or grease by washing in hot water with a mild detergent.
6. Refit the outer filter (C).
7. Refit cover (B).
8. Fasten the three clips (A).



**Do not run the engine with the dust cover (C) removed as this will result in dust ingress and subsequent engine failure.**




## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



## 8.9.1 Air Cleaner

### 8.9.2.3 Check both air-cleaner elements

#### PROCEDURE

1. Observe safety warnings..
2. Release the three clips (A).
3. Remove cover (B).
4. Carefully remove outer filter (C) and inner filter (D).
5. Discard the elements if they are distorted or the bonded gaskets are loose.
6. Hold each element up to the light to check for damage to the paper. The elements should be discarded if pin pricks of light can be seen or if there are areas of paper that appear thin.
7. Refit new or existing elements as required.



**Do not run the engine with the dust cover (C) removed as this will result in dust ingress and subsequent engine failure.**




## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



## 8.9.1 Air Cleaner

### 8.9.2.4 Changing the inner air cleaner element

#### NOTICE

Always obey the air cleaner restriction indicator immediately if the control panel light illuminates. (Never attempt to clean and reuse an element.)

During normal service, the outer element (C) will require replacing only when the restriction indicator is illuminated.

#### PROCEDURE

1. Observe safety warnings.
2. Release the three clips (A).
3. Remove cover (B).
4. Carefully remove outer filter (C).

#### NOTICE

Do not run the engine with the dust cover (C) removed as this will result in dust ingress and subsequent engine failure.

5. Lift the tabs on the outer edge and remove inner element (D).



## HAZARDS

1520 / 1513  
ISO  
1520 / 1513  
ANSI


**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

1532 ISO  
1532 ANSI

**LOCKOUT AND TAGOUT**


Refer this Section, safety information for relevant warning.



## 8.9.1 Air Cleaner

### 8.9.2.4 Changing the inner air cleaner element

6. Clean the inside of the air-cleaner casing using a damp, lint free cloth, paying particular attention to the element seals.
7. Replace the existing inner element (D).
8. Insert outer element (C) into place.
9. Re-fit cover (B).
10. Fasten the three clips (A).



**If the outer element has not been changed for 500 operating hours, a leak in the induction system must be suspected. Check that the air cleaner casing and hoses to the engine are not damaged. Check that all hose connections are airtight.**

## 8.9.3 Electrical safety instructions



Switch off the machine immediately if malfunctions occur in the electrical system.

Before beginning work on any of the machine's electrical components, any power supplied to the machine (whether the battery or a power line) must be cut-off by disconnecting or de-energizing.

Before starting any work, check the machine and the electrical parts to be worked on for the presence of power. Ground or short-circuit the parts to be worked on to prevent the possibility of an electrocution hazard.

Insulate any live parts which cannot be de-energized to prevent the possibility of an electrocution hazard.

Always use insulated tools when working on the electrical systems.



The electrical equipment of the machine is to be inspected and checked at regular intervals. Defects such as loose connections or scorched or otherwise damaged components must be rectified immediately.



Work on the electrical system and equipment of the machine must be carried out by a skilled electrician or by instructed persons under the supervision and guidance of a skilled electrician and in accordance with electrical engineering rules and regulations.

Wiring Diagram see Section 9, "Appendix."

## 8.9.3 Electrical safety instructions

### 8.9.3.1 Check Battery



Always disconnect battery leads before carrying out any maintenance to the electrical system. The battery contains sulphuric acid, electrolyte which can cause severe burns and produce explosive gasses. Avoid contact with the skin, eyes or clothing.

#### PROCEDURE

1. Observe all safety warnings.
2. Ensure that all electrical connections are clean and tight and coat the terminals with petroleum jelly to protect them from corrosion.
3. Disconnect battery at isolator switch **(BIS)** before performing any maintenance.
4. Remove the battery filler plugs and check that the electrolyte level is between 6 and 9 mm (0.25 - 0.37 ins) above the tops of the separators.
5. If necessary, fill up with distilled water.
6. Where batteries have trough fillers, add distilled water to the filling trough until the trough just begins to fill with water.



## HAZARDS

1520 / 1513  
ISO  
1520 / 1513  
ANSI



**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.


1532 ISO  
1532 ANSI

**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.



**OFF**



**ON**




## 8.9.3 Electrical safety instructions

### 8.9.3.2 Battery removal

#### PROCEDURE


1. Observe all safety warnings.
2. Ensure all electrical circuits are switched off.
3. Disconnect battery at isolator switch (**BIS**) before performing any maintenance.
4. Disconnect the ground (-) lead from the battery (B.)
5. Disconnect the positive (+) lead from the battery.
6. Loosen bolts from the battery retaining frame.
7. Remove the battery retaining frame.
8. Lift the battery from the machine.




## HAZARDS

**1520 / 1513 ISO**  
**1520 / 1513 ANSI** **WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO**  
**1532 ANSI** **LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



**BIS - Battery Isolator Switch**



**OFF**

**ON**

**BIS - Battery Isolator Switch**



**Always disconnect battery leads before carrying out any maintenance to the electrical system.**

**The battery contains sulphuric acid, electrolyte which can cause severe burns and produce explosive gasses.**

**Avoid contact with the skin, eyes or clothing.**

## 8.9.3 Electrical safety instructions

### 8.9.3.3 Battery installing

#### PROCEDURE

1. Observe all safety warnings.
2. Ensure all electrical circuits are switched off.
3. Disconnect battery at isolator switch (**BIS**) before performing any maintenance.
4. Lift the battery (B,) onto the machine.
5. Fit the battery retaining frame.
6. Tighten bolts on the battery retaining frame.
7. Connect the positive (+) lead.
8. Connect the ground (-) lead.

#### NOTICE

When installing the battery the positive (+) lead must be connected first. These machines are wired negative ground. Always observe correct polarity.



## HAZARDS

1520 / 1513  
ISO  
1520 / 1513  
ANSI



### WEAR PERSONAL PROTECTIVE EQUIPMENT

Refer this Section, safety information for relevant warning.


1532 ISO  
1532 ANSI

### LOCKOUT AND TAGOUT


Refer this Section, safety information for relevant warning.



**BIS - Battery Isolator Switch**



**OFF**



**ON**

**BIS - Battery Isolator Switch**

## 8.10 Chassis

Check that all bolts and pins are in place and secure.

Check that all guards are fully secured in the closed position.

### 8.10.1 Wheels

Check wheel nuts before every journey.

Check wheel nuts every 150 miles.

After a wheel change, nuts should be checked several times a day until they maintain their correct setting.

(For wheel nut tightening torques, refer to this Section, "adjustment data.")



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**  
Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information  
for relevant warning.

**1509 ISO  
1509 ANSI**

**PRIOR TO TRANSPORT**  
Refer this Section, safety information  
for relevant warning.



## 8.10 Chassis

### 8.10.2 Tyres

Check tyres for damage and deterioration before every journey. Check tyre pressures before every journey.

The tyre pressures must be checked when the tyres are cold.

(For Tyre pressures, refer to this Section “pressures.”)



**Explosive separation of a tyre and rim parts can cause serious injury or death.**

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.

Always maintain the correct tyre pressure. Do not inflate the tyres above the recommended pressure (See this Section, “Pressures.”) When inflating tyres, use a clip-on chuck and extension hose long enough to allow you to stand to one side and not in front or over the tyre assembly. Use a safety cage if available.

Do not attempt to mount a tyre unless you have the proper equipment and experience to perform the job.

Never weld or heat a wheel and tyre assembly. The heat can cause an increase in tyre pressure resulting in a tyre explosion. Welding can also structurally weaken or deform the wheel.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1509 ISO  
1509 ANSI**

**PRIOR TO TRANSPORT**  
Refer this Section, safety information for relevant warning.



## 8.11 Hydraulic system

### NOTICE

The air vents in the cap must be kept open to allow the hydraulic system to “breathe.”

Always use the correct grade of oil, otherwise overheating will occur. (Refer this Section, “lubricants and fluids.”)

If the hydraulic system requires filling up on a regular basis, all hydraulic parts and hoses should be inspected for leaks. Any repairs should be made prior to continued operation of the machine.

**ALWAYS** practice extreme cleanliness when servicing.

- A Hydraulic Oil Level Indicator
- C Filler Cap
- D Drain Plug
- E Suction Filters
- F Return Line Filter



### HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**



**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1504 ISO  
1504 ANSI**

**FLUID INJECTION HAZARD**  
Refer this Section, safety information for relevant warning.



## 8.11.1 Hydraulic oil

### 8.11.1.1 Check hydraulic oil level

#### PROCEDURE

1. Observe all safety warnings.
2. Machine must be on level ground.
3. Always have the hydraulic oil at normal operating temperature.
4. Always have all cylinders retracted (where possible).
5. Check the level indicator (A.)  
The oil level must be between the red and black marks on the gauge.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

### WEAR PERSONAL PROTECTIVE EQUIPMENT

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


### LOCKOUT AND TAGOUT

Refer this Section, safety information for relevant warning.

**1504 ISO  
1504 ANSI**

### FLUID INJECTION HAZARD

Refer this Section, safety information for relevant warning.



## 8.11.1 Hydraulic oil

### 8.11.1.2 Adding hydraulic fluid

#### PROCEDURE

1. Observe all safety warnings.
2. Machine must be on level ground.
3. Always have all cylinders retracted (where possible).
4. Implement lock-out procedure.
5. Clean the area around the filler cap (C.)
6. Open the filler cap (C.)
7. Fill the tank to midway between red and black marks on the level indicator.  
(Correct grade of hydraulic oil see this Section, "lubricants and fluids.")


#### NOTICE

**Never overfill the hydraulic tank as this will cause leakage from the filler cap.**



## HAZARDS

|   |   |
|---|---|
| <b>1520 / 1513 ISO</b><br><b>1520 / 1513 ANSI</b> | <b>WEAR PERSONAL PROTECTIVE EQUIPMENT</b><br>Refer this Section, safety information for relevant warning. |
| <b>1532 ISO</b><br><b>1532 ANSI</b>               | <b>LOCKOUT AND TAGOUT</b><br>Refer this Section, safety information for relevant warning.                 |
| <b>1504 ISO</b><br><b>1504 ANSI</b>               | <b>FLUID INJECTION HAZARD</b><br>Refer this Section, safety information for relevant warning.             |



## 8.11.1 Hydraulic oil

### 8.11.1.3 Change hydraulic oil


#### PROCEDURE


1. Observe all safety warnings.
2. Always have the hydraulic oil at normal operating temperature.
3. Always have all cylinders retracted (where possible.)
4. Drain the tank by removing the drain plug (D.)

#### NOTICE

**ALWAYS practice extreme cleanliness when servicing.**  
**Before removing the drain plug (D.)**

- a) Release any pressure in the hydraulic tank by slowly unscrewing the filler cap (C.)
- b) Ensure a suitable container is placed on the ground to catch the full capacity of oil in the tank.
- c) Remember to stand on one side to avoid oil which will spill from the drain hole.
5. Remove the cover plate under the filler cap (C.)  
Discard the gasket.

|  <b>HAZARDS</b> |   |
|--|---|
| <b>1520 / 1513 ISO</b><br><b>1520 / 1513 ANSI</b>  | <b>WEAR PERSONAL PROTECTIVE EQUIPMENT</b><br>Refer this Section, safety information for relevant warning. |
| <b>1532 ISO</b><br><b>1532 ANSI</b>  | <b>LOCKOUT AND TAGOUT</b><br>Refer this Section, safety information for relevant warning.                 |
| <b>1504 ISO</b><br><b>1504 ANSI</b>  | <b>FLUID INJECTION HAZARD</b><br>Refer this Section, safety information for relevant warning.             |





## 8.11.1 Hydraulic oil


### 8.11.1.3 Change hydraulic oil - CONTINUED

6. Remove the suction filters (E) by unscrewing them from the suction pipes.
7. Flush out the tank with clean hydraulic oil taking extreme care to remove all dirt and foreign matter.
8. Fit new suction filters (E) to the suction pipes.
12. Run the engine to circulate the oil. Operate the hydraulic controls to purge any air from the system.
13. Stop the engine and fill up the system as required.

#### NOTICE

**Change the suction elements when an oil change is being carried out.**

9. Re-fit cover plate to the tank using a new gasket and refit drain plug (D.)
10. Change the return line filter element (refer this Section.)
11. Refill the tank with clean hydraulic oil to midway between the red and black marks on level indicator. (Correct grade of hydraulic oil see this Section, "lubricants and fluids.")



## 8.11.2 Return line filter

### 8.11.2.1 Check return line filter

#### PROCEDURE

1. Observe all safety warnings.
2. Always have the engine running at maximum speed.
3. Always have all hydraulic equipment working.
4. Always have the hydraulic oil at normal operating temperature.
5. Check the return line filter blockage indicator (A.)
6. Change the filter element immediately when the green sector of the blockage indicator goes to red.

#### NOTICE

Red indicates no filtration.

Always change the filter element immediately when the indicator shows red.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1504 ISO  
1504 ANSI**

**FLUID INJECTION HAZARD**  
Refer this Section, safety information for relevant warning.



## 8.11.2 Return line filter

### 8.11.2.2 Change return line filter

#### PROCEDURE

1. Observe all safety warnings.
2. Release any pressure in the hydraulic tanks by slowly unscrewing the filler cap.
3. Clean the outside of the filter housing (C.)
4. Remove the filter by unscrewing the retaining bolts (D.)
5. Lift out the old element (B) and discard it safely.
6. Wash out the filter cap and dry with an air hose. **DO NOT USE A RAG.**
7. Re-fit new filter ensuring seal ring (E) is in good condition and correctly positioned.
8. Tighten cap securely.



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.

**1504 ISO  
1504 ANSI**

**FLUID INJECTION HAZARD**

Refer this Section, safety information for relevant warning.



## 8.12 Maintenance schedules

### 8.12.1 Preventitive CAT/PERKINS Maintenance schedules

The schedules which follow must be applied at the interval (hour or months) which occur first:

- A First service at 20/40 hours
- B Every day or every 8 hours
- C Every 250 hours or 6 months
- D Every 500 hours or 12 months
- E Every 1000 hours
- F Every 2000 hours
- G Every 8000 hours

| A | B | C | D | E | F | G | Operation   |
|---|---|---|---|---|---|---|---|
|   |   |   |   |   |   |   | Check the amount of coolant in the header tank  |
|   |   |   |   |   |   |   | Check the engine for leakage of oil and coolant   |
|   |   |   |   |   |   |   | Check the specific gravity of the coolant   |
|   |   |   |   |   |   |   | Check the tension and condition of the drive belts  |
|   |   |   |   |   |   |   | Clean the sediment chamber and the strainer of the fuel lift pump                         |
|   |   |   |   |   |   |   | Check for water in the pre-filter bowl (or earlier if your fuel supply is contaminated)   |
|   |   |   |   |   |   |   | Renew the element(s) of the fuel filter(s)  |
|   |   |   |   |   |   |   | Ensure that the idle speed is checked and adjusted. If it is necessary                    |
|   |   |   |   |   |   |   | Check the amount of lubricant oil in the sump   |
|   |   |   |   |   |   |   | Check the lubricating oil pressure at the gauge   |
|   |   |   |   |   |   |   | Renew the engine lubricating oil  |
|   |   |   |   |   |   |   | Renew the canister (s) of the lubricating oil filter                                      |
|   |   |   |   |   |   |   | Clean the gauge element of the engine open breather system                                |
|   |   |   |   |   |   |   | Renew the open/closed breather assembly   |
|   |   |   |   |   |   |   | Empty the dust bowl of the air filter   |
|   |   |   |   |   |   |   | extremely dusty conditions  |
|   |   |   |   |   |   |   | normal conditions   |
|   |   |   |   |   |   |   | Clean or renew the air filter element, if it has not been indicated earlier               |
|   |   |   |   |   |   |   | Ensure that the turbo charger impeller and turbocharger compressor casing are cleaned     |
|   |   |   |   |   |   |   | Check all hoses and connections   |
|   |   |   |   |   |   |   | Clean the compressor air filter   |
|   |   |   |   |   |   |   | Ensure that the exhaustor or compressor is checked  |
|   |   |   |   |   |   |   | Check all electric cables and connections   |
|   |   |   |   |   |   |   | Ensure that the valve tip clearances of the engine are checked and, if necessary adjusted |
|   |   |   |   |   |   |   | Ensure that the alternator and the starter motor are checked                              |

## 8.12 Maintenance schedules (Operating hours)

### 8.12.2 Daily (10 hour) maintenance schedule (Machine stopped)

|  | Construction unit/<br>object | Job                       | Remarks | Sign |
|--|------------------------------|---------------------------|---------|------|
| <i>VIEW CONTROL</i>                              |                              |                           |         |      |
|  | Guards                       | check/ replace            |         |      |
|  | Pipelines                    | check/ replace            |         |      |
|  | Valves                       | check/ replace            |         |      |
|  | Bolts and pins               | check/ fasten/<br>replace |         |      |
| <i>ENGINE</i> <i>See engine operation manual</i> |                              |                           |         |      |
|  | Coolant level                | check/ top up             |         |      |
|  | Engine oil level             | check/ top up             |         |      |
|  | Hydraulic oil level          | check/ top up             |         |      |
|  | Fuel tank level              | check/ top up             |         |      |
| <i>MOVING PARTS</i>                              |                              |                           |         |      |
|  | Material build up            | remove                    |         |      |
|  | Moving free                  | check/ ensure             |         |      |
| <i>SCREEN UNIT</i>                               |                              |                           |         |      |
|  | Material build up            | remove                    |         |      |
|  | Screen meshes, wear          | check/ replace            |         |      |
|  | Screen meshes, tension       | check/ tune               |         |      |
|  | Rubber cushions              | check/ replace            |         |      |

## 8.12.2 Daily (10 hour) maintenance schedule (machine running)

|                    | Construction unit/<br>object | Job            | Remarks | Sign |
|--------------------|------------------------------|----------------|---------|------|
| <i>POWER UNIT</i>  |                              |                |         |      |
|                    | Return line filter           | check/ replace |         |      |
| <i>BELTS</i>       |                              |                |         |      |
|                    | Alignment                    | check/ align   |         |      |
|                    | Tension                      | check/tension  |         |      |
| <i>SCREEN UNIT</i> |                              |                |         |      |
|                    | Operation                    | check          |         |      |
|                    | Vibration                    | check/ tune    |         |      |
|                    | Screen shaft speed           | check/adjust   |         |      |

## 8.12.3 Weekly (50 hour) maintenance schedule (machine stopped)

|                                   | Construction unit/<br>object                            | Job                         | Remarks | Sign |
|-----------------------------------|---|-----------------------------|---------|------|
| <i>FIRST</i>                      |   |                             |         |      |
|                                   | Carry out daily (10 hour)<br>maintenance schedule       |                             |         |      |
| <i>FEEDER HOPPER</i>              |   |                             |         |      |
|                                   | Skirting rubbers  | check / adjust /<br>replace |         |      |
|                                   | Feeder gearbox oil                                      | change                      |         |      |
|                                   | Belt cleaners   | check / adjust              |         |      |
| <i>MAIN CONVEYOR</i>              |   |                             |         |      |
|                                   | Belt cleaners   | check / adjust /<br>replace |         |      |
| <i>AUXILLIARY/ SIDE CONVEYORS</i> |   |                             |         |      |
|                                   | Belt cleaners   | check / adjust /<br>replace |         |      |
| <i>TAIL CONVEYOR</i>              |   |                             |         |      |
|                                   | Belt cleaners   | check / adjust /<br>replace |         |      |
| <i>SCREEN UNIT - 2 DECK</i>       |   |                             |         |      |
|                                   | Inner Bearings  | grease                      |         |      |
|                                   | Outer Bearings  | grease                      |         |      |
| <i>SCREEN UNIT - 3 DECK</i>       |   |                             |         |      |
|                                   | Bearings - Over cap                                     | grease                      |         |      |
|                                   | Screen bearings   | oil change /<br>replace     |         |      |
| <i>POWER UNIT</i>                 |   |                             |         |      |
|                                   | After first 50 hours carry out a full<br>engine service |                             |         |      |
|                                   | Engine air filter pre cleaner                           | clean out                   |         |      |
|                                   | Battery electrolyte level                               | check / top up              |         |      |

## 8.12.4 Weekly (100 hour) maintenance schedule (machine stopped)

|                                  | Construction unit/<br>object                       | Job    | Remarks | Sign |
|----------------------------------|--|--------|---------|------|
| <i>FIRST</i>                     |  |        |         |      |
|                                  | Carry out daily (10 hour)<br>maintenance schedule  |        |         |      |
|                                  | Carry out weekly (50 hour)<br>maintenance schedule |        |         |      |
| <i>FEEDER CONVEYOR</i>           |  |        |         |      |
|                                  | Tail drum bearings                                 | grease |         |      |
|                                  | Drive drum bearings                                | grease |         |      |
| <i>MAIN CONVEYOR</i>             |  |        |         |      |
|                                  | Tail drum bearings                                 | grease |         |      |
|                                  | Drive drum bearings                                | grease |         |      |
| <i>AUXILLIARY/SIDE CONVEYORS</i> |  |        |         |      |
|                                  | Tail drum bearings                                 | grease |         |      |
|                                  | Drive drum bearings                                | grease |         |      |
| <i>TAIL CONVEYOR</i>             |  |        |         |      |
|                                  | Tail drum bearings                                 | grease |         |      |
|                                  | Drive drum bearings                                | grease |         |      |



## 8.12.5 250 hour maintenance schedule (machine stopped)

|   | Construction unit/<br>object                       | Job          | Remarks | Sign |
|---|--|--------------|---------|------|
| <i>FIRST</i>  |  |              |         |      |
|   | Carry out daily (10 hour)<br>maintenance schedule  |              |         |      |
|   | Carry out weekly (50 hour)<br>maintenance schedule |              |         |      |
|   | Carry out 100 hour maintenance<br>schedule         |              |         |      |
| <i>POWERUNIT</i> <i>See engine operation manual</i> |  |              |         |      |
|   | Air cleaner elements                               | Check/adjust |         |      |
|   | Water trap fuel system                             | empty        |         |      |

## 8.12.6500 hour maintenance schedule (machine stopped)

|   | Construction unit/<br>object                    | Job          | Remarks | Sign |
|---|---|--------------|---------|------|
| <i>FIRST</i>  |   |              |         |      |
|   | Carry out daily (10 hour) maintenance schedule  |              |         |      |
|   | Carry out weekly (50 hour) maintenance schedule |              |         |      |
|   | Carry out 100 hour maintenance schedule         |              |         |      |
|   | Carry out 250 hour maintenance schedule         |              |         |      |
| <i>POWERUNIT</i> <i>See engine operation manual</i> |   |              |         |      |
|   | Hydraulic oil                                   | Replace      |         |      |
|   | Engine oil filter                               | Replace      |         |      |
|   | Fuel Filter                                     | Replace      |         |      |
|   | Air cleaner inner element                       | Replace      |         |      |
|   | V-belt tolerance                                | Check/adjust |         |      |
|   | Engine Speed                                    | Check/adjust |         |      |
|   | Hydraulic return line filter                    | Replace      |         |      |

## 8.12.7 1000 hour maintenance schedule (machine stopped)

|   | Construction unit/<br>object                       | Job     | Remarks | Sign |
|---|--|---------|---------|------|
| <i>FIRST</i>  |  |         |         |      |
|   | Carry out daily (10 hour)<br>maintenance schedule  |         |         |      |
|   | Carry out weekly (50 hour)<br>maintenance schedule |         |         |      |
|   | Carry out 100 hour maintenance<br>schedule         |         |         |      |
|   | Carry out 250 hour maintenance<br>schedule         |         |         |      |
|   | Carry out 500 hour maintenance<br>schedule         |         |         |      |
| <i>POWERUNIT</i> <i>See engine operation manual</i> |  |         |         |      |
|   | Hydraulic oil                                      | Replace |         |      |

## 8.12.8 2000 hour maintenance schedule (machine stopped)

|  | Construction unit/<br>object                    | Job     | Remarks | Sign |
|--|---|---------|---------|------|
| <i>FIRST</i>   |   |         |         |      |
|  | Carry out daily (10 hour) maintenance schedule  |         |         |      |
|  | Carry out weekly (50 hour) maintenance schedule |         |         |      |
|  | Carry out 100 hour maintenance schedule         |         |         |      |
|  | Carry out 250 hour maintenance schedule         |         |         |      |
|  | Carry out 500 hour maintenance schedule         |         |         |      |
|  | Carry out 1000 hour maintenance schedule        |         |         |      |
| <i>POWER UNIT</i> <i>See engine operation manual /Engine Maintenance Table</i> |   |         |         |      |
|  |   |         |         |      |
| <i>FEEDER GEARBOX</i>  |   |         |         |      |
|  | Oil change                                      | Replace |         |      |

## 8.13 Lubricants and Fluids

| Component                             | International Spec      | Sample   |
|---------------------------------------|-------------------------|--|
| Engine                                | API CD CF<br>CCMC D4    | Shell Fortisol 15W/40<br>Shell Rimula X 15W/40   |
| Hydraulics - up to 30°C               | ISO VG 46               | Shell Tellus 46  |
| Hydraulics - above 30°C               | ISO VG 100              | Shell Tellus 100   |
| Anti-Freeze                           | BS6580<br>ASTM D3306-74 | Shell Safe Anti-Freeze<br>(Ethylene Glycol Based)<br>Shell Save Premium Anti<br>Freeze |
| General Grease                        |                         | Shell Alvania EP2  |
| Grease for Screen Bearings            |                         | Shell Retinax EP2  |
| Gearbox (RMB O95D series)(Beltfeeder) |                         | Shell Tivella SB synthetic<br>gear oil   |
| Gearbox (Brevini 2090 ) (Apron)       |                         | Shell Tivella SB synthetic<br>gear oil   |

### NOTICE

**Always use lubricants and fluids that meet the above international specifications. The Shell grades are for reference only.**

## 8.14 Capacities - Fluid

### CAT C4.4 ACERT

|                             |                  |
|-----------------------------|------------------|
| Engine coolant              | 7.0ltr           |
| Engine oil including filter | 11.0ltr          |
| Hydraulic tank              | 576ltr (153 gal) |
| Fuel tank                   | 336ltr (89 gal)  |

## 8.15 Adjustment Data

|                    |                    |
|--------------------|--------------------|
| Engine speed       | 2200rpm            |
| Screen shaft speed | 970rpm $\pm$ 10rpm |


## 8.16 Pressures

|                  |  |
|------------------|--|
| Hydraulic system | 210bar (3000psi)   |
| Hydraulic hoses  | Pressure rating refer to section 1, "Technical Information." |

## 8.17 Greasing schedule (Lhs and Rh)

(Please note: 20 Grams = approx. 13 grease gun strokes)

| AREA | DESCRIPTION                                     | FREQUENCY | GREASE GUN STROKES |
|------|---|-----------|--------------------|
| 1.   | Feeder Conveyor Tail Drum Bearings Lh/Rh        | 100 HRS   | 2                  |
| 2.   | Apron Feeder Tail Drum Bearings Lh/Rh           | 100 HRS   | 2                  |
| 3.   | Apron Feeder Drive Drum Bearings Lh/Rh          | 100 HRS   | 2                  |
| 4.   | Fines Conveyor Tail Drum Bearing Lh/Rh          | 100 HRS   | 2                  |
| 5.   | Fines Conveyor Drive Drum Bearing Lh/Rh         | 100 HRS   | 2                  |
| 6.   | Oversize Tail Drum Bearings Lh/Rh               | 100 HRS   | 2                  |
| 7.   | Oversize Drive Drum Bearings Lh/Rh              | 100 HRS   | 2                  |
| 8.   | Mid-Fines Tail Drum Bearings Lh/Rh              | 100 HRS   | 2                  |
| 9.   | Mid-Fines Drive Drum Bearings (Lh/Rh)           | 100 HRS   | 2                  |
| 10.  | Tail Conveyor Tail Drum Bearings (Lh/Rh)        | 100 HRS   | 2                  |
| 11.  | Tail Conveyor Drive Drum Bearings (Lh/Rh)       | 100 HRS   | 2                  |
| 12.  | Collection Conveyor Tail Drum Bearings (Lh/Rh)  | 100 HRS   | 2                  |
| 13.  | Collection Conveyor Drive Drum Bearings (Lh/Rh) | 100 HRS   | 2                  |



## 8.18 Recommended Lubricants

|                | Ambient Temperature<br>40 to 95° F<br>4 to 35° C | Ambient Temperature<br>0 to 65° F<br>-18 to 18° C |
|----------------|--|---|
| <b>AMOCO</b>   | Industrial Oil 220                               | Industrial Oil 150                                |
| <b>CHEVRON</b> | AW Machine Oil 220                               | AW Machine Oil 150                                |
| <b>EXXON</b>   | Teresstic 220                                    | Teresstic 150                                     |
| <b>MOBIL</b>   | DTE Oil BB                                       | DTE Oil Extra Heavy                               |
| <b>SHELL</b>   | Turbo 220  | Turbo 150   |
| <b>TEXACO</b>  | Regal R & O 220                                  | Regal R & O 150                                   |

**If ambient temperature exceeds 95° F (35°C) then  
ISO grade 320 should be used**

**Flushing Oil** : Use iso viscosity grade 46 lubricant





| <b>Table of contents</b>                              | <b>Page</b> |
|---|-------------|
| <b>8.1 General information .....</b>                  | <b>4</b>    |
| <b>8.2 Feed conveyor</b>                              |             |
| 8.2.1 Clean & check conveyor belt .....               | 6           |
| 8.2.2 Tensioning the feeder conveyor belt .....       | 7           |
| 8.2.3 Feeder conveyor alignment .....                 | 8           |
| 8.2.4 Tensioning the APRON feeder conveyor belt ..... | 10          |
| <b>8.3 Collection conveyor</b>                        |             |
| 8.3.1 Clean & check conveyor belt .....               | 11          |
| 8.3.2 Tensioning the main conveyor belt .....         | 12          |
| 8.3.3 Main conveyor alignment .....                   | 13          |
| <b>8.4 FINES side conveyor</b>                        |             |
| 8.4.1 Clean & check conveyor belt .....               | 15          |
| 8.4.2 Tensioning the FINES conveyor belt .....        | 16          |
| 8.4.3 FINES conveyor alignment .....                  | 17          |
| <b>8.5 MID-FINES side conveyor</b>                    |             |
| 8.5.1 Clean & check conveyor belt .....               | 19          |
| 8.5.2 Tensioning the MID-FINES conveyor belt .....    | 20          |
| 8.5.3 MID-FINES conveyor alignment .....              | 21          |
| <b>8.6 TAIL conveyor</b>                              |             |
| 8.6.1 Clean & check conveyor belt .....               | 23          |
| 8.6.2 Tensioning the tail conveyor belt .....         | 24          |
| 8.6.3 Tail conveyor alignment .....                   | 25          |
| <b>8.7 LHS side conveyor</b>                          |             |
| 8.7.1 Clean & check conveyor belt .....               | 27          |
| 8.7.2 Tensioning the LHS side conveyor belt .....     | 28          |
| 8.7.3 OVERSIZE conveyor alignment .....               | 29          |
| <b>8.8 Screen unit</b>                                |             |
| 8.8.1 Changing the screen mesh .....                  | 31          |

## Table of contents

## Page

|             |   |    |
|-------------|---|----|
| <b>8.9</b>  | Power unit (Engine operation manual, section 9, Appendix)         | 32 |
| 8.9.1       | Fuel system   |    |
| 8.9.1.1     | Check fuel level .....  | 33 |
| 8.9.1.2     | Adding fuel .....   | 34 |
| 8.9.1.3     | Empty fuel filter water trap .....                                | 35 |
| 8.9.1.4     | Change fuel filter .....  | 36 |
| 8.9.2       | Air cleaner   |    |
| 8.9.2.1     | Changing the outer air cleaner element .....                      | 37 |
| 8.9.2.2     | Clean the precleaner .....  | 39 |
| 8.9.2.3     | Check both air cleaner elements .....                             | 40 |
| 8.9.2.4     | Change inner air cleaner element .....                            | 41 |
| 8.9.3       | Electrical safety instructions(wiring diagrams, Sect 9, Appendix) | 43 |
| 8.9.3.1     | Check battery .....   | 44 |
| 8.9.3.2     | Battery removal .....   | 45 |
| 8.9.3.3     | Battery installing .....  | 46 |
| <b>8.10</b> | <b>Chassis</b>  |    |
| 8.10.1      | Wheels .....  | 47 |
| 8.10.2      | Tyres .....   | 48 |
| <b>8.11</b> | <b>Hydraulic system</b> .....                                     | 49 |
| 8.11.1      | Hydraulic oil   |    |
| 8.11.1.1    | Check hydraulic oil level .....                                   | 50 |
| 8.11.1.2    | Adding hydraulic fluid .....                                      | 51 |
| 8.11.1.3    | Change hydraulic oil filter .....                                 | 52 |
| 8.11.2      | Return line filter  |    |
| 8.11.2.1    | Check return line filter .....                                    | 54 |
| 8.11.2.2    | Change return line filter .....                                   | 55 |

| Table of contents                                   | Page      |
|---|-----------|
| <b>8.12 Maintenance schedules</b>                   |           |
| 8.12.1 Preventive Maintenance schedule .....        | 60        |
| 8.12.2 Daily or 10 hour maintenance schedule .....  | 61        |
| 8.12.3 Weekly or 50 hour maintenance schedule ..... | 63        |
| 8.12.4 100 hour maintenance schedule .....          | 64        |
| 8.12.5 250 hour maintenance schedule .....          | 65        |
| 8.12.6 500 hour maintenance schedule .....          | 66        |
| 8.12.7 1000 hour maintenance schedule .....         | 67        |
| 8.12.8 2000 hour maintenance schedule .....         | 70        |
| <b>8.13 Lubricants and fluids .....</b>             | <b>69</b> |
| <b>8.14 Capacities - Fluid .....</b>                | <b>70</b> |
| <b>8.15 Adjustment Data .....</b>                   | <b>70</b> |
| <b>8.16 Pressures .....</b>                         | <b>70</b> |
| <b>8.17 Greasing Shedule .....</b>                  | <b>71</b> |
| <b>8.18 Recommended Lubricants .....</b>            | <b>72</b> |

## 8.1 General information

When performing maintenance, always observe rules provided in the safety section.

Breakdown caused by insufficient or improper maintenance will cause high repair costs and long term standstill. Therefore, regular maintenance is imperative.

In addition to several other factors, the reliability and life of the H5163 depends on regular and proper maintenance.

The following section contains maintenance instructions as well as maintenance schedules for normal operating conditions.

The machine has been designed to facilitate easy routine maintenance without the removal of any fixed guards.

All greasing points can be accessed from the ground level or any walkways provided and all belt adjustments can be made without removing any protective guards.

If it is necessary to remove any guard doors, all are fitted with captive nuts and bolts to ensure that they are replaced before the machine is restarted.

### NOTICE

**When the H5163 is operated in extreme climatic conditions (e.g. below -15°C or above 33°C) or in very dusty conditions for a long period of time, the maintenance schedules will change.**

**Ask your local POWERSCREEN dealer or POWERSCREEN Aftersales Technical Department for advice.**



## **PRACTICE SAFE MAINTENANCE.**

**Read and understand all service and operation procedures before performing maintenance or operating the machine.**

**Keep work area clean, dry and free from obstacles.**

**Never lubricate, clean, service or adjust machine while it is running.**

**Keep hands, feet and clothing clear of power driven parts and in-running nip points.**

**Before performing maintenance or repairs:**

**(1) Disengage all power and operate controls to relieve all pressure.**

**(2) Stop the engine.**

**(3) Implement lockout procedure.**

**(4) Allow the machine to cool.**

**A raised part of the machine can fall causing serious injuries or death.**

**Always fit the safety support strut provided if any part of the machine, such as a guard door, must be raised for any reason.**

**Never work under unsupported equipment.**

**Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn and broken parts.**

**Remove any build up of grease, oil or debris.**

**Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.**

## 8.2 Feeder conveyor (A2)

### 8.2.1 Clean & check the conveyor belt



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

#### PROCEDURE

1. Observe all safety warnings.
2. Stop the engine.
3. Clean the conveyor belt using a high pressure hose. Ensure that eyes are protected by wearing safety glasses.
4. Check the belt for cuts, tears, rips or any other physical damage.
5. Close and secure the guard doors in the correct position.



**If any damage to the belt is found, do not operate the machine until it is repaired or replaced entirely by your local POWERSCREEN dealer.**




## HAZARDS

**1520 / 1513 ISO**  
**1520 / 1513 ANSI**  
**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO**  
**1532 ANSI**  
**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO**  
**1508 ANSI**  
**FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1502 ISO**  
**1502 ANSI**  
**ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



**H5163 - APRON**



**H5163 - INCLNE**

## 8.2 Feeder conveyor (A2)

### 8.2.2 Tensioning the feeder conveyor belt

#### PROCEDURE

1. Observe all safety warnings.
2. Start the feeder conveyor. (Refer to Section 6, "Operating instructions.")
3. Run the feeder conveyor at desired speed.
4. Tighten the belt by adjusting both belt adjusters (**BA**) evenly

#### NOTICE

Do not overtension the belt as this will damage the drum bearings.



## HAZARDS

1520 / 1513  
ISO  
1520 / 1513  
ANSI



**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

1532 ISO  
1532 ANSI

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

1508 ISO  
1508 ANSI

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.





## 8.2 Feeder conveyor (A2)

### 8.2.3 Feeder conveyor alignment

#### PROCEDURE

1. Observe all safety warnings.
2. Start the feeder conveyor.  
**(H2 - LEVER B4 - RAISE)**  
(Refer to Section 6, "Operating instructions.")
3. Turn control knob of the variable-speed control valve COUNTER-CLOCKWISE to run the feeder conveyor at maximum speed  
**(H2 - FLOW CONTROL e).**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**


**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**H2 b**  
Neutral

**Drive control**



**H2**



## 8.2 Feeder conveyor (A2)

### 8.2.3 Feeder conveyor alignment - CONTINUED

4. Observe the conveyor through the viewing apertures and determine to which side the conveyor is "tracking off."




**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

5. The conveyor is tracking off to the right side.

#### **Solution**


Operate the right side adjuster - one turn at a time until the belt tracks correctly.



The conveyor is tracking off to the left side.

#### **Solution**

Operate the left side adjuster - one turn at a time until the belt tracks correctly.



## 8.2 Feeder conveyor (A2)

### 8.2.4 Tensioning the APRON feeder conveyor belt

#### PROCEDURE

1. Observe all safety warnings.
2. Start the feeder conveyor.  
(Refer to Section 6, "Operating instructions.")
3. Run the feeder conveyor at desired speed.
4. Tighten the belt by adjusting both belt adjusters evenly

#### NOTICE

**Do not overtension the belt as this will damage the drumbearings.**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

### WEAR PERSONAL PROTECTIVE EQUIPMENT

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


### LOCKOUT AND TAGOUT

Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

### FALL HAZARD

Refer this Section, safety information for relevant warning.



## 8.3 Collection conveyor (F)

### 8.3.1 Clean & check the conveyor belt



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

#### PROCEDURE

1. Observe all safety warnings.
2. Stop the engine.
3. Clean the conveyor belt using a high pressure hose. Ensure that eyes are protected by wearing safety glasses.
4. Check the belt for cuts, tears, rips or any other physical damage.



**If any damage to the belt is found, do not operate the machine until it is repaired or replaced entirely by your local POWERSCREEN dealer.**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1502 ISO  
1502 ANSI**

**ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



**Collection conveyor (F)**

## 8.3 Collection conveyor (F)


### 8.3.2 Tensioning the collection conveyor belt

#### PROCEDURE

1. Observe all safety warnings.
2. Start the collection conveyor.  
(Refer to Section 6, "Operating instructions.")  
**(H2- LEVER 7 - RAISE)**
3. Run the collection conveyor at desired speed  
**(H2- FLOW CONTROL C).**
4. Tighten the belt by adjusting both belt adjusters evenly (BA), 2 turns at a time until slippage stops.

#### NOTICE

**Do not over tension the belt as this will damage the drum bearings.**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.




**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



**F**

**H2 b**  
Neutral



## 8.3 Collection conveyor (F)

### 8.3.3 Collection conveyor alignment

#### PROCEDURE

1. Observe all safety warnings.
2. Start the collection conveyor.  
(Refer to Section 6, "Operating instructions.")
3. Move up collection conveyor lever to start collection conveyor  
**(H2-LEVER 7 - RAISE)**.
4. Observe the conveyor through the viewing apertures and determine to which side the conveyor is „tracking off.“



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.


**1502 ISO  
1502 ANSI**

**ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



**Collection conveyor (F)**

**H2 b**  
Neutral



## 8.3 Collection conveyor (F)

### 8.3.3 Collection conveyor alignment - CONTINUED



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

5. The conveyor is tracking off to the right side.



#### **Solution**

Operate the right side adjuster - one turn at a time until the belt tracks correctly.

The conveyor is tracking off to the left side.

#### **Solution**

Operate the left side adjuster - one turn at a time until the belt tracks correctly.





## 8.4 FINES side conveyor (E)

### 8.4.1 Clean & check the conveyor belt



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

#### PROCEDURE

1. Observe all safety warnings.
2. Stop the engine.
3. Clean the conveyor belt using a high pressure hose. Ensure that eyes are protected by wearing safety glasses.
4. Check the belt for cuts, tears, rips or any other physical damage.



**If any damage to the belt is found, do not operate the machine until it is repaired or replaced entirely by your local POWERSCREEN dealer.**




## HAZARDS

**1520 / 1513 ISO**  
**1520 / 1513 ANSI**  
**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO**  
**1532 ANSI**  
**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO**  
**1508 ANSI**  
**FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1502 ISO**  
**1502 ANSI**  
**ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



**E**

#### NOTICE

**The screenbox and FINES side conveyor operate together.**



## 8.4 FINES side conveyor (E)

### 8.4.2 Tensioning the FINES side conveyor belt

#### PROCEDURE

1. Observe all safety warnings.
2. Start the FINES conveyor.  
(Refer to Section 6, "Operating instructions.")
3. Run the FINES side conveyor at desired speed.
4. Tighten the belt by adjusting both belt adjusters evenly, 2 turns at a time until slippage stops.

#### NOTICE

**Do not over tension the belt as this will damage the drum bearings.**




## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**



**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



**H2 b**  
Neutral



## 8.4 FINES side conveyor (E)

### 8.4.3 FINES side conveyor alignment

#### PROCEDURE

1. Observe all safety warnings.
2. Start the FINES conveyor.  
(Refer to Section 6, "Operating instructions.")
3. Move up collection and fines side conveyor lever to start fines side conveyor **(H2-Lever 7 - RAISE)**.
4. Observe the conveyor through the viewing apertures (BA) and determine to which side the conveyor is "tracking off."



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**


**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**


**FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1502 ISO  
1502 ANSI**

**ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



**H2 b**  
Neutral



## 8.4 FINES side conveyor (E)

### 8.4.3 FINES side conveyor alignment - CONTINUED



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

5. The conveyor is tracking off to the right side.



#### **Solution**

Operate the right side adjuster - one turn at a time until the belt tracks correctly.

The conveyor is tracking off to the left side.

#### **Solution**

Operate the left side adjuster - one turn at a time until the belt tracks correctly.



## 8.5 MID FINES side conveyor (D)

### 8.5.1 Clean & check the conveyor belt



Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.

#### PROCEDURE

1. Observe all safety warnings.
2. Stop the engine.
3. Clean the conveyor belt using a high pressure hose. Ensure that eyes are protected by wearing safety glasses.
4. Check the belt for cuts, tears, rips or any other physical damage.



If any damage to the belt is found, do not operate the machine until it is repaired or replaced entirely by your local POWERSCREEN dealer.




## HAZARDS

**1520 / 1513 ISO**  
**1520 / 1513 ANSI** **WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO**  
**1532 ANSI** **LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO**  
**1508 ANSI** **FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1502 ISO**  
**1502 ANSI** **ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



#### NOTICE

The TAIL and MID-FINES side conveyors operate together.

## 8.5 MID FINES side conveyor (D)

### 8.5.2 Tensioning the MID-FINES side conveyor belt

#### PROCEDURE

1. Observe all safety warnings.
2. Start the MID - FINES conveyor.  
(Refer to Section 6, "Operating instructions.")
3. Run the MID-FINES side conveyor at desired speed.
4. Tighten the belt by adjusting both belt adjusters evenly, 2 turns at a time until slippage stops.

#### NOTICE

**Do not over tension the belt as this will damage the drum bearings.**






## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



## 8.5 MID FINES side conveyor (D)

### 8.5.3 MID-FINES side conveyor alignment

#### PROCEDURE

1. Observe all safety warnings.
2. Start the MID- FINES conveyor. (Refer to Section 6, "Operating instructions.")
3. Move up MID-FINES side conveyor lever to start fines side conveyor (**H2-Lever 8 - RAISE**).
4. Observe the conveyor through the viewing apertures and determine to which side the conveyor is "tracking off."

#### NOTICE

The TAIL and MID-FINES side conveyors operate together.




## HAZARDS

**1520 / 1513 ISO**  
**1520 / 1513 ANSI** **WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.


**1532 ISO**  
**1532 ANSI** **LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO**  
**1508 ANSI** **FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1502 ISO**  
**1502 ANSI** **ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



**H2 b**  
Neutral



## 8.5 MID FINES side conveyor (D)

### 8.5.3 MID-FINES side conveyor alignment - CONTINUED





**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

5. The conveyor is tracking off to the right side.

#### **Solution**

Operate the right side adjuster - one turn at a time until the belt tracks correctly.



The conveyor is tracking off to the left side.

#### **Solution**

Operate the left side adjuster - one turn at a time until the belt tracks correctly.

## 8.6 Tail conveyor (C)

### 8.6.1 Clean & check the conveyor belt



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

#### PROCEDURE

1. Observe all safety warnings.
2. Stop the engine.
3. Clean the conveyor belt using a high pressure hose. Ensure that eyes are protected by wearing safety glasses.
4. Check the belt for cuts, tears, rips or any other physical damage.



**If any damage to the belt is found, do not operate the machine until it is repaired or replaced entirely by your local POWERSCREEN dealer.**



## HAZARDS

**1520 / 1513 ISO  
1520 / 1513 ANSI** **WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI** **LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI** **FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1502 ISO  
1502 ANSI** **ENTANGLEMENT MANUAL**  
Refer this Section, safety information for relevant warning.



#### NOTICE

**The TAIL and MID-FINES side conveyors operate together.**



## 8.6 Tail conveyor (C)

### 8.6.2 Tensioning the tail conveyor belt

#### PROCEDURE

1. Observe all safety warnings.
2. Start the tail conveyor.  
(Refer to Section 6, "Operating instructions.")
3. Tighten the belt by adjusting both belt adjusters (BA), 1 off evenly, 2 turns at a time until slippage stops.

#### NOTICE

**Do not overtension the belt as this will damage the drum bearings.**





## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.







3. Observe the conveyor through the viewing apertures (BA) and determine to which side the conveyor is "tracking off."

**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

4. The conveyor is tracking off to the right side.

**Solution**

Operate the right side adjuster - one turn at a time until the belt tracks correctly.



The conveyor is tracking off to the left side.

**Solution**

Operate the left side adjuster - one turn at a time until the belt tracks correctly.

## 8.7 LHS side conveyor (G)

### 8.7.1 Clean & check the conveyor belt



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

#### PROCEDURE

1. Observe all safety warnings.
2. Stop the engine.
3. Clean the conveyor belt using a high pressure hose. Ensure that eyes are protected by wearing safety glasses.
4. Check the belt for cuts, tears, rips or any other physical damage.



**If any damage to the belt is found, do not operate the machine until it is repaired or replaced entirely by your local POWERSCREEN dealer.**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



## 8.7 LHS side conveyor (G)

### 8.7.2 Tensioning the LHS side conveyor belt

#### PROCEDURE

1. Observe all safety warnings.
2. Start the RH side conveyor. (Refer to Section 6, "Operating instructions.")
3. Tighten the belt by adjusting both belt adjusters (BA), 1 off evenly, 2 turns at a time until slippage stops.

#### NOTICE

Do not overtension the belt as this will damage the drum bearings.





## HAZARDS

1520 / 1513  
ISO  
1520 / 1513  
ANSI

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

1532 ISO  
1532 ANSI

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.



## 8.7 LHS side conveyor

### 8.7.3 LHS side conveyor alignment



## HAZARDS

**1520 / 1513  
ISO  
1520/ 1513  
ANSI**

### WEAR PERSONAL PROTECTIVE EQUIPMENT

Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**


### LOCKOUT AND TAGOUT

Refer this Section, safety information  
for relevant warning.


## PROCEDURE

1. Observe all safety warnings.
2. Start the LHS side conveyor.  
**(H2 - LEVER 8 - RAISE)**  
(Refer to Section 6,  
"Operating instructions.")


**H2**



**G**



**H2 b**  
Neutral



## 8.7 LHS side conveyor

### 8.7.3 LHS side conveyor alignment - CONTINUED

3. Observe the conveyor and determine to which side the conveyor is "tracking off."



**Do not unfasten or remove any guard while the machine is running or start the machine while a guard is unfastened or removed.**

4. The conveyor is tracking off to the right side.



#### **Solution**

Operate the right side adjuster - one turn at a time until the belt tracks correctly.

The conveyor is tracking off to the left side.


#### **Solution**

Operate the left side adjuster - one turn at a time until the belt tracks correctly.



## 8.8 Screenuint

### 8.8.1 Changing the screen mesh

**WARNING**  Never allow unqualified personnel to attempt to operate, maintain, remove or replace any part of the machine.  
Never allow anyone to remove large or heavy components without adequate lifting tackle.

#### *PROCEDURE*

1. Observe all safety warnings.
2. **REFER TO CEDARAPIDS MANUAL FOR OPERATION AND MAINTENANCE SCREEN UNIT PROCEDURES.**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.



## 8.9 Power unit

For any maintenance on the power unit see engine operation manual in Section 9, "Appendix," "List of attached documentation."

## 8.9.1 Fuel system

### 8.9.1.1 Check fuel level

#### PROCEDURE

1. Observe all safety warnings.
2. Check the level indicator (A.)
3. Fill the tank at the end of each day, where possible, to reduce overnight condensation within the tank.



**Diesel fuel is highly flammable.**

**Never remove filler cap or refuel, with the engine running.**

**Never add gasoline or any other fuel mixes to diesel because of increased fire or explosion risks.**

**Do not smoke or carry out maintenance on the fuel system near open flame or sources of sparks, such as welding equipment, etc..**



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**



**WEAR PERSONAL PROTECTIVE EQUIPMENT**

Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**

Refer this Section, safety information for relevant warning.



## 8.9.1 Fuel system

### 8.9.1.2 Adding fuel

#### NOTICE

**DO NOT** fill the tank to capacity.

**Monitor** gauge on tank side.

**Allow** room for expansion and wipe up spilt fuel immediately, otherwise paintwork will be damaged.

#### PROCEDURE

1. Observe all safety warnings.
2. Clean the area around the filler cap.
3. Remove the filler cap.
4. Fill the tank with diesel.



**Diesel fuel is highly flammable.**

**Never** remove filler cap or refuel, with the engine running.

**Never** add gasoline or any other fuel mixes to diesel because of increased fire or explosion risks.

**Do not** smoke or carry out maintenance on the fuel system near open flame or sources of sparks, such as welding equipment, etc..





## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**LOCKOUT AND TAGOUT**  
Refer this Section, safety information for relevant warning.





## 9.1 Designs

### H5163R

|       |   |   |
|-------|---|---|
| 9.1.1 | General plan .....  | 2 |
| 9.1.2 | Working Dimensions .....  | 3 |
| 9.1.3 | Transport Dimensions .....                                      | 4 |
| 9.1.4 | Work Area Required - excluding stockpiles (Track Machine) ..... | 5 |

### H5163

|       |  |   |
|-------|--|---|
| 9.1.5 | Transport Dimensions .....                   | 6 |
| 9.1.6 | Working Dimensions - Aerial view .....       | 7 |
| 9.1.7 | Working Dimensions - Side and End View ..... | 8 |


### H5163R + H5163

|       |                    |   |
|-------|--------------------|---|
| 9.1.8 | Noise levels ..... | 9 |
|-------|--------------------|---|


## 9.2 Enclosed documentation

Engine operation manual  
Engine spare parts manual


## 9.1.1 H5163R - General plan



## 9.1.2 H5163R - General plan - Working Dimensions




## 9.1.3 H5163R - Transport Dimensions







## 9.1.4 H5163R and H5163 - Working Area Required




## 9.1.4 H5163 - Transport Dimensions




## 9.1.5 H5163 - Working Dimensions



## 9.1.6 H5163 - Working Dimensions - End and Side View



## 9.1.7 H5163R + H5163 - Noise levels M/c running empty





## CONTENTS

|                                      |   |
|--------------------------------------|---|
| 10.1 General Troubleshooting.....    | 2 |
| 10.2 Electrical Troubleshooting..... | 3 |
| 10.3 Engine Troubleshooting.....     | 5 |
| 10.4 Hydraulic Troubleshooting.....  | 7 |
| 10.5 Tracks Troubleshooting.....     | 8 |

### **NOTICE**

#### **TROUBLE SHOOTING GUIDE**

If any problem arises that is not listed, or if a problem persists after carrying out the recommended checks, contact Powerscreen Aftersales Service Department for further assistance.

## 10.1 GENERAL TROUBLESHOOTING

| FAULT  | CAUSE   | CORRECT MEASURE   |
|--|---|---|
| <b>DRIVE DRUM TURNS BUT BELT DOES NOT MOVE</b>                               | Too much load on belt   | Reduce load on belt   |
|  | Incorrectly tensioned belt  | Tension belt  |
|  | Worn belt   | Replace belt  |
| <b>BELT COMPLETELY STOPPED</b>   | Material jam  | Remove material jam   |
|  | Taperlock is not tight or broken  | Tighten or replace taperlock  |
| <b>BELTS ARE TRACKING OFF</b>  | Machine is not level  | Ensure machine is on level ground                                       |
|  | Belts are not aligned   | Align belts   |
|  | Belts are not being fed evenly, material is tending to be fed to one side of conveyor | Ensure conveyor is fed more evenly                                      |
| <b>MATERIAL COLLECTS UNDER BELT</b>  | Skirting rubbers not adjusted   | Adjust skirting rubbers   |
| <b>FEEDER CONVEYOR IS NOT MOVING</b>   | Feeder kickout circuit has been activated   | Allow material in drum to be processed before re-engaging control lever |
| <b>RUMBLING NOISE FROM BEARING</b>   | Bearing lacking lubricant   | Follow greasing procedure   |
|  | Incorrectly aligned bearing   | Align bearing   |
|  | Bearing is damaged  | Replace bearing   |
| <b>SCREECHING NOISE WHEN CONVEYOR IS RUNNING</b>                             | Conveyor belt wedged or rubbing against fixed parts                                   | Clear obstruction, adjust and align conveyor belt                       |
|  | Belt scaper too tightly placed against belt   | Re-adjust belt scaper   |
| <b>TIPPING GRID WILL NOT OPERATE IN EITHER MANUAL OR REMOTE CONTROL MODE</b> | Low battery charge level  | Charge battery. Top up electrolyte level                                |
|  | Insufficient flow to hydraulic ram  | Check flow from pump and control valve                                  |
|  | Electrical problem  | Check fuses, relays and all connections                                 |
|  | Poor hydraulic ram condition  | Replace hydraulic ram   |
|  | Poor connection between tipping grid receiver and solenoids                           |   |
|  | Damaged solenoid  | Replace solenoid  |



## 10.1 GENERAL TROUBLESHOOTING (CONTINUED)

| FAULT  | CAUSE  | CORRECT MEASURE   |
|--|--|---|
| <b>MACHINE COMPONENTS RUNNING SLOWLY</b>         | Obstruction (e.g stone, material build up etc)   | Clear obstruction   |
|  | Check general condition of machine (e.g oil leaks, excessive heat, hose blockages etc) | Correct problem if possible   |
|  | Low engine speed   | Correct engine speed  |
|  | Low hydraulic oil level.   | Top up hydraulic oil level  |
|  | Return line filter blockage  | Replace return line filter  |
|  | Pre-pump filter blockage   | Replace suction strainer  |
|  | Machine is overloaded  | Check mesh size calculations, alter screen angle  |
|  | Incorrect control valve relief valve pressure settings                                 | Check and correct relief pressure setting   |
|  | Incorrect Pressure relief block pressure settings                                      | Check and correct relief pressure setting   |
|  | Pump cavitation, suction line is collapsed   | Open gate valve<br>Low oil level  |
|  | Flow at pump is not as expected  | Check flow after pump, after control valve and after motor. These values should be the same |
| <b>MACHINE WILL NOT JACK TO WORKING POSITION</b> | Machine is not level   | Place machine on level ground   |
|  | Securing pins not removed  | Remove securing pins  |
|  | Blockage along hose  | Remove blockage, replace hose if necessary  |
|  | Incorrect control valve relief pressure  | Correct control valve relief pressure   |
| <b>EXCESSIVELY NOISY PUMP</b>                    | Blockage at pre pump filter  | Replace suction strainer  |
|  | Misalignment between drive source and pump   | Correctly align drive source to pump  |
|  | Incorrect hydraulic oil  | Drain hydraulic and replace with correct hydraulic oil                                      |
|  | Obstruction at inlet pipe  | Remove obstruction  |

## 10.1 GENERAL TROUBLESHOOTING (CONTINUED)

| FAULT                                  | CAUSE  | CORRECT MEASURE   |
|--|--|---|
| <b>VIBRATION IN SCREENBOX SUBFRAME</b> | Build up of material   | Remove build up and ensure build up is regularly removed. In some cases it may be |
|  | Anti - rock stays have not been removed  | Remove anti rock stays  |
|  | Meshes are not secure  | Ensure all meshes, speedharps, punchplate etc are secure                          |
|  | Machine and Screenbox are not level  | Ensure machine and screenbox are level  |
|  | Screen shaft is not at correct speed   | Correct screen shaft speed  |
|  | Screenbox is incorrectly tuned   | Tune screenbox by correctly adding or removing weight                             |
|  | Flywheels are not correctly aligned with screen shaft scribe line                        | Align flywheels   |
|  | Bearing failure (excessive heat, excessive grease, lack of grease or excessive movement) | Replace bearing   |
|  | Excessive feed overloading   | Coordinate feed loading with tuning of screenbox, adjust screen angle             |
| <b>LOW OR ERRATIC PRESSURE</b>         | Contaminants in hydraulic oil  | Drain tank and replace hydraulic oil  |
|  | Worn or sticking relief valve  | Replace relief valve  |
|  | Dirt or chip holding valve partially open  | Clean around valve. Replace valve   |
|  | Control valve relief pressure set too low  | Set relief pressure to correct level  |

## 10.2 ELECTRICAL TROUBLESHOOTING

| FAULT  | CAUSE  | CORRECT MEASURE   |
|--|--|---|
| 7 SECOND DELAY<br>WARNING SIREN<br>DOES NOT WORK           | Fuse F5 blown  | Replace fuse  |
|  | Siren have been damaged                              | Replace siren   |
| CONTROL PANEL<br>LIGHTS UP BUT<br>ENGINE DOES NOT<br>START | Low engine oil level (warning<br>light should be on) | Top up oil level  |
|  | Faulty starter motor relay 5                         | Replace starter motor<br>relay 5                        |
|  | Faulty ignition switch                               | Replace ignition switch                                 |
|  | Faulty starter motor                                 | Replace starter motor                                   |
| CONTROL PANEL<br>DOES NOT LIGHT UP                         | Low battery voltage                                  | Top up electrolyte level                                |
|  |  | Charge up battery                                       |
|  | Fuse F1 blown  | Replace fuse  |
|  | Faulty ignition switch<br>terminals                  | Correct connections /<br>replace                        |
| BATTERY GOES FLAT<br>WHILE ENGINE IS<br>RUNNING            | Damaged battery                                      | Replace battery   |
|  | Low battery voltage                                  | Top up electrolyte level                                |
|  |  | Charge up battery                                       |
|  | Fuse F5 blown  | Replace fuse  |
|  | Faulty starter motor relay 5                         | Replace starter motor<br>relay 5                        |
| TIPPING GRID<br>REMOTE CONTROL<br>DOES NOT WORK            | Faulty starter motor                                 | Replace starter motor                                   |
|  | Remote control is out of<br>range                    | Move remote control to<br>within 100m of the<br>machine |
|  | Batteries are dead                                   | Replace batteries                                       |
|  | Tipping grid cycle not set                           | Set program   |
|  | Remote control not<br>programmed to receiver box     | Program receiver box                                    |

## 10.2 ELECTRICAL TROUBLESHOOTING (CONTINUED)

| FAULT                                   | CAUSE   | CORRECT MEASURE  |
|---|---|--|
| TRACKS RADIO CONTROL UNIT DOES NOT WORK | Not correctly charged                           | Charge battery   |
|   | Changeover switch not engaged                   | Engage changeover switch   |
| TRACKS DO NOT WORK                      | Control bank levers are not in correct position | Place control bank levers in correct position  |
|   | Fuse F3 blown                                   | Replace fuse and check for short circuit between control panel, track junction box and doglead |

## 10.3 ENGINE TROUBLESHOOTING

|    | Common causes of symptoms   | SYMPTOM                                |  |                                |                            |                                      |   |                                     |                   |                    |                    | Measure         |
|----|---|--|--|--------------------------------|----------------------------|--------------------------------------|---|-------------------------------------|-------------------|--------------------|--------------------|-----------------|
|    |   | Engine non-start or difficult to start | Engine starts, but runs irregularly or fails | Engine becomes excessively hot | Engine output is deficient | Engine does not run on all cylinders | Engine oil pressure is non-existent or very low | Engine oil consumption is excessive | Engine smoke blue | Engine smoke white | Engine smoke black |                 |
| 1  | Not declutched  | X                                      |  |                                |                            |                                      |   |                                     |                   |                    |                    | Check           |
| 2  | Below starting limit temperature  | X                                      |  |                                |                            |                                      |   |                                     |                   | X                  |                    | Check           |
| 3  | Engine shut off lever still in stop position (shutoff magnet defective) | X                                      |  |                                | X                          |                                      |   |                                     |                   |                    |                    | Check           |
| 4  | Oil level too low   |  |  | X                              |                            |                                      | X   |                                     |                   |                    |                    | Top up          |
| 5  | Oil level too high  |  |  | X                              | X                          |                                      |   | X                                   | X                 |                    |                    | Check           |
| 6  | Excessive inclination of engine   |  |  |                                |                            |                                      | X   | X                                   | X                 |                    |                    | Check / Adjust  |
| 7  | Adjust throttle to half actuation travel                                | X                                      |  |                                |                            |                                      |   |                                     |                   |                    |                    | Check / Adjust  |
| 8  | Air cleaner clogged / turbocharger                                      |  |  | X                              | X                          |                                      |   |                                     |                   |                    | X                  | Check / Replace |
| 9  | Air cleaner service switch / indicator defective                        |  |  | X                              | X                          |                                      |   |                                     |                   |                    | X                  | Check           |
| 10 | CPD defective (connection line leaks)                                   |  |  |                                | X                          |                                      |   |                                     |                   |                    | X                  | Check           |
| 11 | Charge air line leaking   |  |  | X                              | X                          |                                      |   |                                     |                   |                    | X                  | Check / Replace |
| 12 | Coolant pump defective  |  |  | X                              |                            |                                      |   |                                     |                   |                    | X                  | Check / Clean   |
| 13 | Intercooler soiled  |  |  |                                | X                          |                                      |   |                                     |                   |                    |                    | Check / Clean   |
| 14 | Coolant heat exchanger soiled   |  |  | X                              |                            |                                      |   |                                     |                   |                    |                    | Check / Clean   |
| 15 | Cooling fan defective, torn or loose V belt Fuel pump in belt drive)    | X                                      | X  | X                              | X                          | X                                    |   |                                     |                   |                    |                    | Check / Replace |
| 16 | Cooling air temperature rise / heating short circuits                   |  |  | X                              | X                          |                                      |   |                                     |                   |                    |                    | Check           |
| 17 | Battery defective or discharged   | X                                      |  |                                |                            |                                      |   |                                     |                   |                    |                    | Check           |

CPD = Charge Pressure Dependant

**NOTICE**

From Deutz 2012 engine manual

## 10.3 ENGINE TROUBLESHOOTING (CONTINUED)

|    |  | SYMPTOM   |  |                                |                            |                                      |   |                                     |                   |                    |                    | Measure                 |
|----|--|---|--|--------------------------------|----------------------------|--------------------------------------|---|-------------------------------------|-------------------|--------------------|--------------------|-------------------------|
|    |  | Engine non-start or difficult to start                            | Engine starts, but runs irregularly or fails | Engine becomes excessively hot | Engine output is deficient | Engine does not run on all cylinders | Engine oil pressure is non-existent or very low | Engine oil consumption is excessive | Engine smoke blue | Engine smoke white | Engine smoke black |                         |
| 18 | Most common cause of symptom                   | Cable connections, starter, electrical, circuit loose or oxidised | X  |                                |                            |                                      |   |                                     |                   |                    |                    | Check                   |
| 19 | Starter defective or pinion does not engage    | X   |  |                                |                            |                                      |   |                                     |                   |                    |                    | Check                   |
| 20 | Incorrect valve                                | X   | X  |                                | X                          |                                      |   |                                     |                   | X                  | X                  | Adjust                  |
| 21 | Injection line leaks                           | X   | X  |                                | X                          | X                                    |   |                                     |                   |                    |                    | Check                   |
| 22 | Ventilation line blocked (coolant heat)        |   |  | X                              |                            |                                      |   |                                     |                   |                    |                    | Check / Clean           |
| 23 | Sheathed glow plugs defective                  | X   |  |                                |                            |                                      |   |                                     |                   | X                  |                    | Check                   |
| 24 | Injection valve defective                      | X   | X  | X                              | X                          | X                                    |   |                                     |                   | X                  | X                  | Check / Replace         |
| 25 | Air in the fuel system                         | X   | X  |                                | X                          | X                                    |   |                                     |                   |                    |                    | Check / Replace         |
| 26 | Fuel filter / fuel pre-cleaner soiled          | X   | X  |                                | X                          | X                                    |   |                                     |                   |                    |                    | Check / Clean / Replace |
| 27 | Oil filter defective                           |   |  | X                              |                            |                                      |   |                                     |                   |                    |                    | Replace                 |
| 28 | Incorrect engine lube oil SAE class or quality | X   |  |                                |                            |                                      | X   | X                                   |                   |                    |                    | Replace                 |
| 29 | Fuel quality not as per operation manual       | X   | X  |                                | X                          |                                      |   |                                     |                   | X                  |                    | Check / Replace         |
| 30 | Coolant deficiency                             |   |  | X                              |                            |                                      |   |                                     |                   |                    |                    | Check / Top up          |

## 10.4 HYDRAULIC TROUBLESHOOTING

| FAULT  | CAUSE   | CORRECT MEASURE                      |
|--|---|--------------------------------------|
| <b>NO RESPONSE FROM ANY HYDRAULIC SYSTEM</b>           | Low oil level   | Top up hydraulic oil level           |
|  | Return line element is clogged (Check blockage indicator) | Replace return line element          |
|  | Damaged suction line                                      | Replace suction line pipe            |
|  | Pressure relief valve stuck in open position              | Replace valve                        |
| <b>MACHINE OPERATING SLOWLY. NO EXTERNAL OIL LEAKS</b> | Low oil level   | Top up hydraulic oil level           |
|  | Incorrect hydraulic oil                                   | Drain tank and replace hydraulic oil |
|  | Engine performance  | Consult engine manual                |
|  | Loose or damaged taperlocks                               | Tighten / replace taperlock          |
|  | Worn or damaged drive motor                               | Replace motor                        |
|  | Worn or damaged pump                                      | Replace pump                         |
| <b>EXCESSIVE NOISE FROM HYDRAULIC PUMP</b>             | Low oil level causing cavitation                          | Top up oil level                     |
|  | Incorrect hydraulic oil (fluid viscosity too high)        | Drain tank and replace hydraulic oil |
|  | Damage to suction pipe                                    | Replace pipe                         |
|  | Misaligned drive source (engine or motor) to pump         | Align pump correctly                 |
|  | Damaged pump  | Replace pump                         |

## 10.5 TRACKS TROUBLESHOOTING

### **(i) One Track not operating or operating slower than the other**

- Check that the same size of Motors have been fitted to both Tracks.
- Check if the brake is releasing.

Fit a pressure clock to the Brake Hose. A pressure of at least 285 PSI / 20 bar is required to release the brakes.

If the correct pressure is not going to the Brake hose it is likely to be a problem with the Motion Control Block possibly contamination. If a Load Control Valve should jam due to oil-entrained debris then the likelihood is that it will not open and will not allow the motor to turn in one direction.

This will cause the Host Machine to 'crab' in one direction. Swapping the valves over from one Track to the other will usually transfer the problem to the opposite direction.

Similarly, if the Brake Pressure Regulator Valve is jammed due to debris the motor will stop turning on one side. Swap the Pressure Regulator from the opposite block to see if the problem is in the Brake Valve.

Try removing the Valves and cleaning them thoroughly taking care not to damage the external cavity seals.

Also check the ports in the Block for dirt etc. If this does not work replace the valves with new ones. Always cross-reference the part numbers on the new valves with the old valve, before fitting. It is critical that the correct Valves are fitted. Valves should never be dismantled as no internal seals or parts are available.

If the valves continue to jam then the oil in the hydraulic system is not being filtered to the required level of cleanliness.

- If the correct pressure is going to the Brake Hose then the Motor, Brake or Brake Piston Seals may be damaged.
- To check for a Motor fault swap over the Motors on the two Tracks. If the fault is in the Motor, replace with a new Motor.
- To check for a faulty Brake remove the Motor and look into the Gearbox for heat discolouration and/or fragments of Brake disc. If the fault is in the Brakes the complete Gearbox will have to be replaced.
- To check for faulty Brake Piston seals remove the Motor. If there is Hydraulic oil in the Gearbox entrance then the seals are damaged. While it may be possible to replace these seals on-site we strongly recommended that a replacement Gearbox is fitted and an overhaul of the damaged Gearbox be carried out off-site.



## 10.5 TRACKS TROUBLESHOOTING (CONTINUED)

### (ii). Excessive oil leaking around Drive Assembly

- Seals damaged between Motion Control Block and Motor.

Remove Motion Control Block and replace seals.

**Note:** Seal damage may be caused by excessive oil temperatures. Check oil operating temperature and environmental conditions.

- Seal damaged between Motor and Gearbox.

Remove Motor and replace seal.

**Note:** Seal damage may be caused by excessive oil temperatures. Check oil operating temperature and environmental conditions.

### (iii) Track will not stay tensioned

- Grease escaping.

Check that the Track Adjuster Grease Valve is tight, has a properly fitted seal and that there is no grease leaking past it.

Check around the Tensioning Cylinder for escaping grease. This will indicate that the seals are damaged in the Tensioning Cylinder. Replace with a new Cylinder immediately.

### (iv) Track Group running off Sprocket and/or Idler

- Track Group too loose. Check Track tension
- Excessive misalignment. Check alignment of Sprocket, Idler and Track Rollers.
- Excessive component wear. Check wear limits,
- Twisted Track Frame. Check Track Frame.

### (v) Excessive Component Wear Rate

- Included in this section

### (vi) Track Roller leaking oil

- Damaged or worn seals. Replace with a new Track Roller.




## CONTENTS

|      |                               |   |
|------|-------------------------------|---|
| 11.1 | General Fault Finding.....    | 2 |
| 11.2 | Electrical Fault Finding..... | 4 |


## 11.1 Hydraulic Fault Finding

### 11.1.1 None of the machine hydraulics are working when the machine is switch on



## 11.1 Hydraulic Fault Finding

### 11.1.2 One circuit is not working, all other circuits are working



**Always ensure hydraulic test unit is fully open when connecting to circuit**


**Never attach a hydraulic test unit between the pump and a control valve and restrict the flow using the adjustable screw**

**Never attach any measurement device that restricts or blocks flow from a pump**

**THIS WILL CAUSE SERIOUS DAMAGE TO THE PUMP**


## 11.2 Electrical fault finding

### 11.2.1 Control panel switches on but engine will not crank




## 11.2 Electrical fault finding

### 11.2.2 Engine will crank but NOT start




**11.2 Electrical fault finding**  
**11.2.3 Control panel will NOT switch ON**





## 11.2 Electrical fault finding

### 11.2.4 Battery goes flat while engine is running





## FAULT FINDING

H 5163R / H 5163

Issue 06 EG

Page 8



## Contents

|  |   |
|--|---|
| 12.1 Plant Tracks .....                | 2 |
| 12.2 Measuring Track Tension .....     | 3 |
| 12.3 Adjusting Track Tension .....     | 4 |
| 12.4 GEARBOX OIL LEVEL .....           | 6 |
| 12.5 DRAINING GEARBOX OIL .....        | 7 |
| 12.6 TRACK OPERATING PRECAUTIONS ..... | 8 |
| 12.7 Cleaning the tracks .....         | 9 |

## 12.1 - Plant Tracks

### PROCEDURE

Keeping the track correctly adjusted will increase the service life of the track and drive components.  
Frequently check for loose bolts, oil leaks, master pins are correctly located and tight, general wear and damage, correct track tension, etc. to ensure safe working and long life



### HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE  
EQUIPMENT**  
Refer this Section, safety information  
for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information  
for relevant warning.

**1532 ISO  
1532 ANSI**

**SWITCH OFF AND LOCKOUT**  
Refer this Section, safety information  
for relevant warning.

### !NOTICE!

To maximise the life of the track, keep it movable and avoid damage, the plant should be moved at least every week, by a distance exceeding four times the track length. It should also be parked on level ground overnight and during periods to of non-usage. This is particularly important when working in adverse conditions.

It is essential that the tracks are correctly tensioned at all times. Check track tension regularly.

Moving the plant with incorrectly tensioned tracks can cause severe damage to the undercarriage components and may invalidate the warranty.


## 12.2 Measuring Track Tension

1. Observe all Safety Warnings.
2. Position the plant on solid and level ground and drive 2 metres (2 yards) minimum in a forward direction, track idler roller leading.
3. Close down the plant and implement the Lockout Procedure.
4. One track at a time, measure the sag on the top part of the track on the longest section of unsupported track by placing a 'straight edge' long enough to reach from the drive sprocket to the nearest skid plate.
5. Measure the maximum amount of track sag from the high point of the track to the bottom of the 'straight edge'.  
Correctly adjusted, the sag should be within the limits set for each supplier as shown in the table below.
6. Depending upon the need to either slacken or tension the track, proceed as follows.

### WARNING

Prior to attempting any manoeuvring of the plant the tracks must be free of obstructions, including crushed material and fines. Do not push or tow the plant. Failure to observe this warning could result in injury to persons and damage to the plant which may invalidate warranty.

It is important that the track is not tensioned too tightly as this places excessive loads on the gearbox grease cylinder and idler bearings. It will also lead to accelerated wear and premature failure.



| IDENTIFICATION | SAG VALUE   |
|----------------|-------------|
| TRACKLINE      | 5MM - 15MM  |
| STRICKLINE     | 5MM - 15MM  |
| TEREX          | 20MM - 40MM |

## 12.3 Adjusting Track Tension

1. Observe all Safety Warnings.
2. Close down the plant and implement the Lockout Procedure.
3. Locate the access aperture on the side of the track frame and remove the cover, where fitted, to reveal the relief valve inside.

To Release Track Tension [After measurement]:-

4. Loosen the relief valve by turning counter clockwise using gradual increments until the grease begins to be expelled. Care must be taken not to loosen the relief valve too quickly because the grease inside is under high pressure.
5. When the correct track tension has been measured, turn the relief valve clockwise to tighten and then clean away all trace of expelled grease.
6. If the track fails to slacken after the grease fitting has been loosened, do not attempt to remove the tracks or disassemble the track tensioner, or remove the grease fitting. It is possible that running the tracks with the grease fitting loosened may help to expel the grease



## HAZARDS

**1520 / 1513  
ISO  
1520 / 1513  
ANSI**

**WEAR PERSONAL PROTECTIVE EQUIPMENT**  
Refer this Section, safety information for relevant warning.

**1508 ISO  
1508 ANSI**

**FALL HAZARD**  
Refer this Section, safety information for relevant warning.

**1532 ISO  
1532 ANSI**

**SWITCH OFF AND LOCKOUT**  
Refer this Section, safety information for relevant warning.

### WARNING

Grease escaping under high pressure. Grease can penetrate the skin. Ensure correct personal protective equipment is worn.

### DANGER

Grease coming out of the relief valve under pressure can penetrate the body causing injury or death; DO NOT watch the relief valve to see if grease is escaping but instead watch the track adjustment cylinder to verify that the track is being loosened.

## 12.3 Adjusting Track Tension - CONTINUED

To Increase Track Tension [After measurement]:-

7. Connect the grease gun to the grease fitting and add grease until the track tension is within the specified dimension, see 'Measuring Track Tension' and refer to lubricant and fluid specifications.

Re-check Tension

8. Operate the plant in track mode and drive the plant 50 metres (50 yards) forwards and 50 metres (50 yards) backwards, check track tension and repeat the above steps if it is within the specified dimension, see 'Measuring Track Tension'.
9. If room for manoeuvring the plant is restricted, drive the plant forwards and backwards several times over a shorter distance.

**DO NOT SET TRACK TENSION  
TOOTIGHT.**

## 12.4 GEARBOX OIL LEVEL

### CHECKING AND FILLING GEARBOX OIL

- 1 Ensure machine is switched off, locked out and tagged out. Remove ignition key, carry it with you.
- 2 Move the machine to a level surface and bring the oil drain holes to the position shown in fig 28.4.
- 3 Thoroughly clean around both plugs removing all potential contaminants.
- 4 Remove both plugs.
- 5 Fill the oil through the upper hole until it runs out through the lower hole.
- 6 Wait a few moments until any trapped air has escaped and then re-check the level. Add more oil if necessary.

#### NOTICE

Cleanliness is essential when checking, filling or replacing oil in the gearbox. Gearbox operating life will be dramatically shortened if the oil becomes contaminated. Only use new clean oil in clean containers and fillers.

#### NOTICE

The Gearbox should hold approximately 5 litres of oil, which should be filtered through a 10 micron filter before entering the gearbox.

Oil Fill Hole

Oil Drain  
Hole




Fig 28.4




## 12.5 DRAINING GEARBOX OIL

- 1 Ensure machine is switched off, locked out and tagged out.  
Remove ignition key, carry it with you
- 2 Move the machine to a level surface and bring the oil fill and oil drain holes to the position shown in fig 28.5
- 3 Thoroughly clean around both plugs removing all potential contaminants.
- 4 Remove both plugs and allow the oil to drain. The oil will drain quickly if it is hot, however care should be taken to avoid burns to the operator.
- 5 Move the machine to bring the plugs to the fill position shown in fig 28.5

Do not move the machine any further until the gearbox oil has been replaced


- 6 Re fill the oil

Dispose of oil safely and in a environmentally friendly manner



## 12.6 TRACK OPERATING PRECAUTIONS

When traveling up a gradient, the tracks should be driven forward (i.e idlers first, drive sprocket to the rear). When traveling down a gradient, tracks should be driven sprocket



### ALWAYS:-

Park the machine on flat, level ground. If necessary to park the machine on a gradient, the tracks should be solidly blocked.

Ensure the terrain the machine is working on is firm enough to adequately support the machine.

Ensure the machine is tracked at least 10m in either direction on a daily basis, to minimize risk of track chain seizure.

Ensure the track systems are free from debris before moving the machine.

Ensure the tracks are not frozen to the ground before moving the machine.

### NEVER:-

Attempt to track the machine if there is any build up of material around the tracks and drive sprockets.

Attempt to track the machine if the tracks are frozen to the ground.

Push or tow the machine when unable to free itself.



Failure to observe the above precautions could result in danger to persons and damage to the track systems and may also invalidate the warranty.

## 12.7 Cleaning the tracks

1. Observe all safety warnings.
2. On a daily basis the tracks should be hosed down to dislodge any build up of material on the tracks.

|  <b>HAZARDS</b> |  |
|--|--|
|                 | <b>LOCK-OUT MACHINE.</b><br>Refer this Section, Safety information, for relevant Lock-Out procedure.       |
|                 | <b>WEAR PERSONAL PROTECTIVE EQUIPMENT.</b><br>Refer this Section, safety information for relevant warning. |



